

SNAP PAC MOTION CONTROL USER'S GUIDE

SNAP-SCM-MCH16 Motion Module
SNAP-SCM-BB4 Breakout Board
OptoMotion Command Set

Form 1673-220718—July 2022

OPTO 22
Automation made simple.

43044 Business Park Drive • Temecula • CA 92590-3614
Phone: 800-321-OPTO (6786) or 951-695-3000
Fax: 800-832-OPTO (6786) or 951-695-2712
www.opto22.com

Product Support Services

800-TEK-OPTO (835-6786) or 951-695-3080
Fax: 951-695-3017
Email: support@opto22.com
Web: support.opto22.com

SNAP PAC Motion Control User's Guide
Form 1673-220718—July 2022

Copyright © 2003–2022 Opto 22.

All rights reserved.

Printed in the United States of America.

The information in this manual has been checked carefully and is believed to be accurate; however, Opto 22 assumes no responsibility for possible inaccuracies or omissions. Specifications are subject to change without notice.

Opto 22 warrants all of its products to be free from defects in material or workmanship for 30 months from the manufacturing date code. This warranty is limited to the original cost of the unit only and does not cover installation, labor, or any other contingent costs. Opto 22 I/O modules and solid-state relays with date codes of 1/96 or newer are guaranteed for life. This lifetime warranty excludes reed relay, SNAP serial communication modules, SNAP PID modules, and modules that contain mechanical contacts or switches. Opto 22 does not warrant any product, components, or parts not manufactured by Opto 22; for these items, the warranty from the original manufacturer applies. These products include, but are not limited to, OptoTerminal-G70, OptoTerminal-G75, and Sony Ericsson GT-48; see the product data sheet for specific warranty information. Refer to Opto 22 form number 1042 for complete warranty information.

Wired+Wireless controllers and brains are licensed under one or more of the following patents: U.S. Patent No(s). 5282222, RE37802, 6963617; Canadian Patent No. 2064975; European Patent No. 1142245; French Patent No. 1142245; British Patent No. 1142245; Japanese Patent No. 2002535925A; German Patent No. 60011224.

Opto 22 FactoryFloor, *groov*, Optomux, and Pamux are registered trademarks of Opto 22. Generation 4, *groov* Server, ioControl, ioDisplay, ioManager, ioProject, ioUtilities, *mistic*, Nvio, Nvio.net Web Portal, OptoConnect, OptoControl, OptoDataLink, OptoDisplay, OptoEMU, OptoEMU Sensor, OptoEMU Server, OptoOPCServer, OptoScript, OptoServer, OptoTerminal, OptoUtilities, PAC Control, PAC Display, PAC Manager, PAC Project, SNAP Ethernet I/O, SNAP I/O, SNAP OEM I/O, SNAP PAC System, SNAP Simple I/O, SNAP Ultimate I/O, and Wired+Wireless are trademarks of Opto 22.

ActiveX, JScript, Microsoft, MS-DOS, VBScript, Visual Basic, Visual C++, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. Linux is a registered trademark of Linus Torvalds. Unicenter is a registered trademark of Computer Associates International, Inc. ARCNET is a registered trademark of Datapoint Corporation. Modbus is a registered trademark of Schneider Electric, licensed to the Modbus Organization, Inc. Wiegand is a registered trademark of Sensor Engineering Corporation. Nokia, Nokia M2M Platform, Nokia M2M Gateway Software, and Nokia 31 GSM Connectivity Terminal are trademarks or registered trademarks of Nokia Corporation. Sony is a trademark of Sony Corporation. Ericsson is a trademark of Telefonaktiebolaget LM Ericsson. CompactLogix, MicroLogix, SLC, and RSLogix are trademarks of Rockwell Automation. Allen-Bradley and ControlLogix are registered trademarks of Rockwell Automation. CIP and EtherNet/IP are trademarks of ODVA.

groov includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org>)

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

Opto 22
Automation Made Simple.

Table of Contents

Chapter 1: Overview	1
Introduction	1
Software Availability	2
Compatibility	2
About this Guide	2
Related Documentation	3
For Help	3
Chapter 2: Specifications	5
Module Specifications	5
Module Bias and Termination	6
Module LEDs	6
Breakout Board Specifications	7
Breakout Board LEDs	7
Power and Serial LEDs	7
Axis LEDs	7
Breakout Board Connector Pins	8
J2: Serial Connector	8
J3 (and J6, J9, & J12): Encoder Signal Inputs	8
J4 (and J7, J10, & J13): Stepper Motor Outputs	8
J5 (and J8, J11, & J14): Stepper Motor Inputs	8
J15: Auxiliary Power Input	8
Breakout Board Switches	9
SW1–SW8: Signal Selection for Encoder Inputs	9
S3 (and S5, S4, & S6): Enable/Disable Axis	9
S7: Bias & Termination, Voltage Select, Breakout Board Address	9
S1 & S2: Pull-up Resistors	9
If Pull-Up Resistors Are Not Used	10
RS-422/485 Serial Cable	10
Calculating Power Requirements	10
Chapter 3: Hardware Quick Start	11
What You Will Need	11
Setting Up the SNAP-SCM-MCH16 Module	12

Removing a Module	14
Configuring the Breakout Board.....	15
Assigning an IP Address to the Controller or Brain	17
Checking the Firmware Version of the Controller or Brain	19
Component Connection Schematic	20
Connecting Multiple Breakout Boards	21
Daisy-Chained Breakout Boards Schematic	22

Chapter 4: Commands Quick Start23

Introduction	24
Using the Example Strategies	24
How To Structure a Motion Control Strategy in PAC Control	25
1: Open a communication handle	25
2: Reset the axes	25
3: Configure parameters	26
4: Enable each axis	26
5: Close the communication handle	27
How To Find Home.....	27
Single Axis Example	27
Multiple Axis Example	28
Moving a Set Distance.....	29
Using a Smooth Start and Smooth Stop	29
Host I/O Errors	30
How To Use the Command Details	31
Entering Commands in OptoScript.....	32
Response Format.....	33

Chapter 5: Command Reference35

Commands by Group.....	36
Commands in Alphabetical Order	38

Appendix: SNAP-SCM-MCH16 Conversion Formulas 111

Overview

Introduction

The easy-to-use SNAP PAC Motion Control Subsystem provides an integrated hardware and software toolset for controlling multi-axis stepper motors. The subsystem consists of:

- SNAP Motion Control host communication modules (SNAP-SCM-MCH16)
- SNAP Motion Control breakout boards (SNAP-SCM-BB4)
- OptoMotion command set.



The **SNAP-SCM-MCH16** motion control host module is a serial communication module that links up to four SNAP-SCM-BB4 motion control breakout boards with a SNAP PAC I/O unit. When mounted on an I/O unit and connected to a breakout board, a single SNAP-SCM-MCH16 module allows a SNAP PAC controller running a PAC Control™ programming strategy to control up to 16 stepper motors. The module snaps into an Opto 22 SNAP PAC mounting rack right beside digital and analog modules. LED indicators are provided to indicate Transmit and Receive on each port.

Each SNAP-SCM-BB4 breakout board is equipped with a Magellan™ processor chip set that outputs pulse and direction signals for up to four stepper motor systems. You can daisy-chain up to four breakout boards connected to a single module. The module's external connector provides lines to power one breakout board; additional boards require a separate power source. The SNAP-SCM-BB4 breakout board is designed to be mounted using a DIN-rail system. For additional information on using the Magellan™ Motion Processor, see version 1.x of the *Magellan™ Motion Processor User's Guide* available on the web at www.pmdcorp.com.

The **OptoMotion** commands supports many of the Magellan™ Motion Processor commands. These commands are entered in a PAC Control strategy as text strings using the Transmit String and Receive commands or the TransmitReceiveString command in OptoScript. The OptoMotion commands give you the ability to define and acquire motion process data such as position, velocity, acceleration, breakpoints, interrupts, and time intervals. In addition, you can execute motion-related actions such as smooth stops, stepping, and position adjustments.

Software

SNAP PAC controllers use Opto 22's **PAC Project** Microsoft® Windows®-compatible automation software for programming, human-machine-interface (HMI) development, and OPC connectivity. Two versions of PAC Project are available:

- **PAC Project Basic** includes PAC Control for developing control programs, PAC Display™ for creating operator interfaces, and PAC Manager™ configuration software.
- **PAC Project Professional** adds expanded versions of PAC Control and PAC Display plus OptoOPCServer™ software for exchanging data with OPC 2.0-compliant client software applications.

For more information, see the *PAC Project Data Sheet*.

Software Availability

PAC Project Basic is included with SNAP PAC controllers and is a free download from the Opto 22 website. PAC Project Professional is available for purchase on a CD with both Acrobat PDF format and printed documentation.

To get PAC Project Professional immediately, you can buy and download the software from the Opto 22 website at www.opto22.com; the CD and printed documentation will be shipped to you. You can also separately purchase PAC Control Professional, PAC Display Professional, and OptoOPCServer as needed. For additional information, see the *PAC Project data sheet*, Opto 22 form 1699.

Compatibility

SNAP-SCM-MCH16 motion modules are designed to work with SNAP PAC mounting racks. For information on using older SNAP racks, see form 1688, *SNAP PAC System Migration Tech Note*.

About this Guide

This guide shows you how to install and use the SNAP PAC Motion Control Subsystem. This guide assumes that you know how to create a strategy in PAC Control, and how to use motion control technology. If you are not familiar with these subjects, we strongly suggest you consult commercially available resources to learn about them before attempting to install or use the SNAP PAC Motion Control Subsystem.

The following sections are included in this user's guide:

Chapter 1, "Overview"—Information about the guide and how to reach Opto 22 Product Support.

Chapter 2, "Specifications"—Specifications of the SNAP-SCM-MCH16 module and SNAP-SCM-BB4 breakout board.

Chapter 3, "Hardware Quick Start"—Quick-start steps to get SNAP PAC Motion Control Subsystem up and running quickly.

Chapter 4, "Commands Quick Start"—How to use the OptoMotion library of motion commands, which you can use within PAC Control strategies.

Chapter 5, “Command Reference”—A list of the motion control commands by group, and a detailed explanation of each command listed in alphabetical order.

Appendix A, “SNAP-SCM-MCH16 Conversion Formulas”—Provides a table for converting Counts/Cycle used by some of the motion commands.

Related Documentation

See the following documents for additional information.

For this information	See this guide	Form #
Designing flowchart-based control programs for the system	<i>PAC Control User's Guide</i>	1700
	<i>PAC Control Command Reference</i>	1701
Configuring I/O points and system functions	<i>PAC Manager User's Guide</i>	1704
Installing and using SNAP PAC brains and I/O units.	<i>SNAP PAC Brains User's Guide</i>	1690
Installing and using Opto 22's SNAP PAC R-series of programmable automation controllers	<i>SNAP PAC R-Series Controllers User's Guide</i>	1595

For Help

If you have problems installing or using SNAP PAC Motion Control Subsystem, first check this guide and the Troubleshooting section of the user's guide for your Opto 22 hardware. If you cannot find the help you need in the guides or on the Opto 22 website, contact Opto 22 Product Support.

Phone:	800-TEK-OPTO (800-835-6786) 951-695-3080 (Hours are Monday through Friday, 7 a.m. to 5 p.m. Pacific Time)	<i>NOTE: Email messages and phone calls to Opto 22 Product Support are grouped together and answered in the order received.</i>
Fax:	951-695-3017	
Email:	support@opto22.com	
Opto 22 website:	www.opto22.com	

Specifications

This chapter provides specifications of the SNAP-SCM-MCH16 module and SNAP-SCM-BB4 breakout board.

In This Chapter


- Module Specificationsbelow
- Breakout Board Specifications 7
- RS-422/485 Serial Cable 10
- Calculating Power Requirements 10

Module Specifications

Baud rates	115,200
Parity	Even
Data bits	8 only
Logic supply voltage	5.0 to 5.2 VDC
Logic supply current	250 mA ¹ 500 mA ²
Number of ports per module	1
Maximum number of modules per rack	8 ¹
Maximum cable length, multi-drop	1,000 feet at 115,200 Baud
I/O processor (brain or on-the-rack controller) compatibility	SNAP-PAC-R1, SNAP-PAC-R2, SNAP-PAC-EB1, or SNAP-PAC-EB2
Operating temperature	-20 to 70 °C
Storage temperature	-30 to 85 °C
Torque, hold-down screws	4 in-lb (0.45 N-m)
Torque, connector screws	5.26 in-lb (0.6 N-m)
Agency Approvals	UL, CE, RoHS, DFARS
Warranty	30 months

1. Each breakout board is powered by a separate power supply.
2. Breakout board uses power from the module.


Module Bias and Termination



Module LEDs

Transmit and receive LEDs are provided as shown in the diagram at right.

LED	Indicates
1	Power Supply Fault
2	Tx
3	Status
4	Rx



Power Supply Fault indicates a fault on the internal power supply of the module (too much draw). This will happen if more than one breakout board is connected without additional power supplies, or there is a short in the system.

Tx: transmitting data

Status: shows module status. This LED blinks twice when the kernel is started.


Rx: receiving data

Breakout Board Specifications

Power Requirements	8.0 to 32.0 VDC @ 250mA 5.00 to 5.20 VDC @ 500mA
Operating Temperature	-20 to 70 °C
Relative Humidity	95%, non-condensing
Agency Approvals	UL, DFARS
Warranty	30 months


Breakout Board LEDs

There are LED indicators for power and serial, and there are four sets of LEDs for the axis connections, one for each axis.




Power and Serial LEDs

The power and serial LEDs indicate the following:




Axis LEDs

There is one set of LED indicators for each axis that indicates the following:



Breakout Board Connector Pins



J15: Auxiliary Power Input

Pin	Description
1	Aux +5Vin
2	Aux +8-24Vin
3	GND
4	Chassis GND

J2: Serial Connector

Pin	Description
1	ToHost+
2	ToHost-
3	GND
4	FromHost+
5	FromHost-
6	Chassis GND
7	VMod
8	VMod
9	GND
10	GND

J4 (and J7, J10, & J13): Stepper Motor Outputs

Pin	Description
1	Pulse+
2	Pulse-
3	GND
4	Direction+
5	Direction-
6	AtRest+
7	AtRest-
8	GND
9	AxisOut+
10	AxisOut-


J3 (and J6, J9, & J12): Encoder Signal Inputs

Pin	Description
1	QuadA+
2	QuadA-
3	GND
4	QuadB+
5	QuadB-
6	Index+
7	Index-
8	GND
9	Home+
10	Home-


J5 (and J8, J11, & J14): Stepper Motor Inputs

Pin	Description
1	PosLimit
2	GND
3	NegLimit
4	GND
5	AxisIn
6	GND

Breakout Board Switches




SW1–SW8: Signal Selection for Encoder Inputs



All up=Non-differential
All down=Differential


Position	Description
SW1 (and SW3, SW5, & SW7)	
1 & 2	QuadA
3 & 4	QuadB
SW2 (and SW4, SW6, & SW8)	
1 & 2	Index
3 & 4	Home

S1 & S2: Pull-up Resistors




Switch	Axis	Description
S1: J5 & J8 470 Ohm Pull Up Resistors		
1	0	PosLimit
2	0	NegLimit
3	0	AxisIn
4	1	PosLimit
5	1	NegLimit
6	1	AxisIn
S2: J11 & J14 Pull Ups		
1	2	PosLimit
2	2	NegLimit
3	2	AxisIn
4	3	PosLimit
5	3	NegLimit
6	3	AxisIn

S3 (and S5, S4, & S6): Enable/Disable Axis



Position	Enable/Disable
Up	Disable
Middle	Enable
Down	Enable

S7: Bias & Termination, Voltage Select, Breakout Board Address



Switch	Description
1	ToHost Termination
2	FromHost Termination
3	VMod/Aux +8-24Vin Select*
4	
5	ADDR0
6	ADDR1

* Set both switches to ON for VMod, or both to OFF for Aux +8-24Vin.


Use switches 5 and 6 to set the address as follows:

Switch 5 (ADDR0)	Switch 6 (ADDR1)	Address
OFF	OFF	0
ON	OFF	1
OFF	ON	2
ON	ON	3

If Pull-Up Resistors Are Not Used


If pull-up resistors are not used, the inputs shown on [page 9](#) (see “S1 & S2: Pull-up Resistors”) will be floating and could cause unexpected behavior if not driven by an external source.

If driven to +5v, the Limit inputs will be asserted. If driven to GND, the Limit inputs will be de-asserted. See circuit below. If you wish to invert this logic, see the [SetSignalSense](#) command. If you wish to disable the limit inputs, see the [SetLimitSwitchMode](#) command on [page 93](#).



RS-422/485 Serial Cable

Use the following schematic to build the RS-422/485 cable that connects the module to the breakout board. The connectors (Opto part numbers 6346 and R80088) are provided in the motion control kit.



SNAP-SCM-MCH16		SNAP-SCM-BB4	
Description	Pin	Pin	Description
GND	1, 2	3, 9, 10	GND
TX+	3	4	FROM HOST+
TX-	4	5	FROM HOST-
RX+	5	1	TO HOST+
RX-	6	2	TO HOST-
VMOD*	7, 8	7, 8	VMOD*

* VMOD can only power one SNAP-SCM-BB4

Calculating Power Requirements

When you assemble a SNAP rack that includes a SNAP-SCM-MCH16, you need to calculate the power requirements to make sure that the rack’s power supply is adequate for the combined current needed by the brain or controller and all the I/O modules. For more information and power requirements worksheets, see the *SNAP I/O Wiring Guide* (form 1403) as well as the wiring appendices in the brain or controller’s user’s guide.

Hardware Quick Start

This chapter describes how to set up the Motion Control Subsystem hardware.

In This Chapter

What You Will Need.....	below
Setting Up the SNAP-SCM-MCH16 Module	12
Configuring the Breakout Board	15
Component Connection Schematic	20
Connecting Multiple Breakout Boards	21

What You Will Need

To set up the Motion Control Subsystem you need the following things:

- SNAP-SCM-MCH16 motion module
- SNAP-SCM-BB4 motion control breakout board
- RS-422/485 serial cable (see “RS-422/485 Serial Cable” on page 10)
- PC running Opto 22 PAC Project software version 8.0 or newer
- SNAP PAC rack-mounted controller or brain with firmware version 8.0 or newer.

NOTE: The I/O unit must be part of a system using PAC Control on a SNAP PAC controller.

- A SNAP PAC rack


NOTE: Assemble the hardware according to the directions that came with it. For help with wiring, see product data sheets, which are available on our website at www.opto22.com.

- Power supply
- Stepper motor

Setting Up the SNAP-SCM-MCH16 Module


The SNAP-SCM-MCH16 module snaps into place in the row of connectors on any SNAP PAC rack. Each module connector has a number.

1. Set the termination and bias for the SNAP-SCM-MCH16 as follows:



2. Place the rack so that the module connector numbers are right-side up, with zero on the left.
3. With the power off, position the SNAP-SCM-MCH16 module over the module connector in position 0, aligning the small slot at the base of the module with the retention bar on the rack.

The module can be placed in any position on the rack. This example shows the module in position 0.



4. With the module correctly aligned over the connector, push on the module to snap it into place.



When positioning modules next to each other, be sure to align the male and female module keys (shown in the detailed view in the illustration at right) before snapping a module into position.

Modules snap securely into place and require a special tool (provided) to remove them. To remove a module, see [page 14](#).

5. As shown in the photo at right, use standard 4-40 x 1/4 truss-head Phillips hold-down screws to secure both sides of each module.


CAUTION: Do not over-tighten screws.

6. Make sure the rack is wired to receive 5.0 to 5.2 VDC @ 4A. Leave the power supply off at this time. For more information on power requirements, see , the SNAP I/O Racks Data Sheet.



Removing a Module

1. If the module is held in place with screws, remove them.
2. Holding the SNAP module tool (provided) as shown in the illustration at right, insert it into the notch at the base of the module.
3. Squeeze the module tool against the module to open the release latch, and pull straight up on the module to remove it.



Configuring the Breakout Board


For breakout board layout information, see [“Breakout Board Specifications” on page 7](#).

- Decide which of the following example strategies you want to use. For the Electronic Gearing Example you will need to attach a stepper motor (described below) to Axis 0 and Axis 1. For all other example strategies you only need a stepper motor on axis 0.
 - Electronic Gearing Example
 - S-Curve Contouring Example
 - Trapezoidal Contouring Example
 - Velocity Contouring Example


For more information, see [“Using the Example Strategies” on page 24](#).

- (Optional) If you have an encoder, set the Signal Selection switches for Axis 0 (SW1 and SW2) as shown below for your encoder type. If you are using the Electronic Gearing example strategy, also set the switches for Axis 1 (SW3 and SW4). For help locating the switches on the board, see [“Breakout Board Switches” on page 9](#).


If your encoder outputs differential signals, make sure they are in the Differential Signals position: all *down*.



If your encoder outputs non-differential signals, make sure they are in the Non-Differential Signals position: all *up*.




- Enable Axis 0 by setting S3 to the Enabled position. If you are using the Electronic Gearing example strategy (see [page 24](#)), enable Axis 1 too by setting S5 to the Enabled position.




4. Set the SNAP-SCM-BB4 address and termination on S7 as shown at right.



5. Connect the SNAP-SCM-MCH16 to the SNAP-SCM-BB4 with the RS-422/485 serial cable (see [“RS-422/485 Serial Cable”](#) on page 10).



6. Connect your stepper motors to the SNAP-SCM-BB4. Minimum connections are Pulse, Direction, and GND. Make sure you have a power supply for the stepper motor. To locate the connector pins on the board, see [“Breakout Board Connector Pins”](#) on page 8.



7. (Optional) If you have an encoder, see [“Breakout Board Connector Pins”](#) on page 8 to locate and connect the connector pins.
8. If the controller or brain on the rack already has an IP address, skip to [“Checking the Firmware Version of the Controller or Brain”](#) on page 19. If not (as indicated by the STAT LED on controller or brain blinking orange), assign an IP address by following the steps in the next section.

Assigning an IP Address to the Controller or Brain

The following instructions for assigning an IP address are provided here in simplified form for your convenience. For detailed instructions on assigning an IP address, please see form 1704, the *PAC Manager User's Guide*.

Before you begin, please note the following:

- All SNAP Ethernet-based controllers and brains must be assigned a unique, static IP address. If the network you're using has a Dynamic Host Configuration Protocol (DHCP) server, either assign a static IP address before connecting the device to the network (preferred), or disable the server. (These servers may respond to BootP requests and assign a dynamic address.)

CAUTION: To make sure the controller or I/O unit is not on a network with a DHCP server, we recommend you use a crossover cable with a direct connection to assign IP addresses.

- If you are adding an I/O segment to an existing Ethernet network, your network administrator must provide static IP addresses and subnet masks for the I/O units. If you are creating an independent, dedicated Ethernet network just for I/O, you can choose your own addresses.
- You will need to know the device's MAC address. The MAC address is printed on a label on the side of the device.
- BootP broadcasts cannot get through a firewall in the PC where PAC Manager is running. Make sure any firewall in the computer (such as the built-in firewall in Windows XP) is disabled before you try to assign IP addresses. Firewalls in a router should not be a problem.

To assign an IP address:

1. Connect the device (controller or brain) using ETHERNET 1. (Only Ethernet 1 sends a BootP request.)

NOTE: As stated in the CAUTION above, we recommend you use a crossover cable with a direct connection to assign IP addresses.


2. Choose Start > Programs > Opto 22 > PAC Project > PAC Manager.
3. Choose Tools > Assign IP Address.

In the dialog that opens you should see the device's MAC address. Addresses of other Opto 22 Ethernet-based devices without IP addresses might appear as well.



4. Turn on the controller.
5. Double-click the MAC address of the device to open the Mapping dialog box.

CAUTION: PAC Manager lists ALL Opto 22 devices sending BootP or DHCP broadcasts. Assign IP addresses only to the ones you know are yours!



6. Enter an IP Address and Subnet Mask compatible with your network.

WARNING! Each device on your network, including computers, routers, controllers, brains, and so on, must have a unique IP address. Failure to assign unique IP addresses may cause catastrophic network or hardware failures. If you don't know which IP addresses are safe to use, check with your system administrator.

7. When the IP address, subnet mask, and other fields are correct, click OK.


The new IP address information appears in the upper list in the dialog box, and the device's status changes to Mapped. The address information also appears in the lower list to show that this device has been mapped to this address.

8. With the device still highlighted, click Assign.

The address is saved to flash memory, and the status changes to Static IP.

9. To verify that the IP address has been successfully assigned, highlight the device in the upper list and click Test.

A DOS window opens and the IP address is automatically contacted using the PING program. You should see a reply similar to the following:



If you don't see a reply, make sure the subnet mask you've assigned matches the subnet mask on your PC.


10. For future reference, write the IP address next to the MAC address on the white sticker provided on the device, then close the DOS window.

11. Click Close to exit.

Next you will check to make sure the controller or brain is running firmware version 8.0 or newer.

Checking the Firmware Version of the Controller or Brain

1. Choose Start > Programs > Opto 22 > PAC Project > PAC Manager.
2. In the PAC Manager main window, click Inspect .
3. In the IP Address field, type the IP address of the SNAP-PAC-R controller or brain, and then click Status Read.




Firmware version

If you don't have firmware version 8.0 or newer, new firmware can be downloaded from our website, www.opto22.com. For information on how to load new firmware, see Chapter 6 of the *PAC Manager User's Guide*, form 1704.

Component Connection Schematic


The following schematic shows a basic connection of one module to one breakout board, and includes an optional encoder.



Connecting Multiple Breakout Boards


You can daisy-chain up to four breakout boards as shown here. The first breakout board in the chain receives power from the motion module, while each additional breakout board requires its own external power supply. The boards are connected with serial RS-422/485 cables. You can connect up to four stepper motors per breakout board. Also see the schematic on the next page.

A PC is used to develop and maintain a PAC Control strategy. The strategy is downloaded to the controller where it runs independently of the PC.



Daisy-Chained Breakout Boards Schematic

Use the following schematic to daisy-chain SNAP-SCM-BB4 breakout boards.



SNAP-SCM-BB4		Next SNAP-SCM-BB4	
Description	Pin	Pin	Description
TO HOST+	1	1	TO HOST+
TO HOST-	2	2	TO HOST-
GND	3	3	GND
FROM HOST+	4	4	FROM HOST+
FROM HOST-	5	5	FROM HOST-

Commands Quick Start

This chapter gets you started using the OptoMotion library of motion commands, which you can use within PAC Control strategies.

In This Chapter

Introduction	24
Using the Example Strategies	24
How To Structure a Motion Control Strategy in PAC Control	25
How To Find Home	27
Moving a Set Distance.....	29
Using a Smooth Start and Smooth Stop.....	29
Host I/O Errors.....	30
How To Use the Command Details.....	31
Entering Commands in OptoScript.....	32
Response Format.....	33

Introduction

The OptoMotion commands support many of the Magellan™ Motion Processor commands, giving you the ability to define and acquire motion process data such as position, velocity, acceleration, breakpoints, interrupts, and time intervals. In addition, you can execute motion-related actions such as smooth stops, stepping, and position adjustments.

Commands are sent to the SNAP-SCM-MCH16 motion module via PAC Control. The SNAP-SCM-MCH16 motion module acts as a communication link between Opto 22 controllers and the SNAP-SCM-BB4 breakout board. Using a PAC Control strategy, you open a TCP Communication Handle to the module. Then you use Transmit/Receive in an OptoScript block to send to the module native English text commands used by the motion processor. The module converts the text strings to binary commands, which it then passes to the motion processor on the breakout board to control the motion of a stepper motor.

You can also use standard PAC Control blocks to enter the motion control commands. However, this typically takes several blocks in a strategy, so it is usually better to use OptoScript. For detailed descriptions of the available commands, see the commands starting on [page 38](#).

Using the Example Strategies

Four example strategies are available on the Opto 22 website, www.opto22.com. [Click here](#), or else navigate to the [Downloads](#) section and search for “Motion_Control_Example_Strategies.zip”.

The ZIP file contains the following example strategies:

- **Electronic Gearing Example:** causes axis 0 and axis 1 to rotate for 10 seconds and then stop for 10 seconds.
- **S-Curve Contouring Example:** turns the motor a quarter turn every 10 seconds. This example uses the S-curve profiling mode.
- **Trapezoidal Contouring Example:** Turns the motor a quarter turn every 10 seconds. This example uses the Trapezoidal profiling mode.
- **Velocity Contouring Example:** Turns axis 0 on for 10 seconds then off for 10 seconds.

You can use the example strategies as a starting point for creating your own control strategies. In particular, take a look at the OptoScript blocks, Axis Setup and Axis 0 Move for each example. The Axis Setup block initializes the SNAP-SCM-BB4 and the Axis 0 Move block makes axis 0 move.

If you don't have PAC Control you can download it from our website, www.opto22.com. For the Electronic Gearing Example you need a stepper motor attached to axis 0 and axis 1. For all other example strategies you only need a stepper motor on axis 0.

To use an example strategy:

1. Unzip the examples from the CD provided to a directory on your local hard drive, and then open one of the strategies.
2. With an example strategy open in Configure mode or Online mode, double-click the Control Engines folder on the Strategy Tree and add the control engine as described in Chapter 5 of the *PAC Control User's Guide*, form 1700.

In the Control Engine dialog box, you only need to enter a descriptive Control Engine Name and the Primary IP address, which is the address of the controller. In the Configure Control Engines dialog box, make sure to select the control engine and click Set Active.

3. Close the dialog boxes for adding a control engine.
4. Choose Mode > Debug.
The strategy is downloaded to the controller.
5. Click Run Strategy ▶, then attend to any dialog boxes that might appear.
At this point your stepper motor should be spinning.

How To Structure a Motion Control Strategy in PAC Control

A motion control strategy in PAC Control should have the following structure:

- 1: [Open a communication handle \(page 29\)](#)
- 2: [Reset each axis \(page 29\)](#)
- 3: [Configure parameters \(page 30\)](#)
- 4: [Enable each axis \(page 31\)](#)
- 5: [Close the communication handle \(page 32\)](#)

Also see, “[Entering Commands in OptoScript](#)” on [page 32](#) and “[Response Format](#)” on [page 33](#).

1: Open a communication handle

Before anything else, open a communication handle in your PAC Control strategy using the Open Outgoing Communication command.

For example, the comm handle used in this example is `comMotionModule`.

```
Open Outgoing Communication
Communication Handle comMotionModule
Put Result in comMotionModule_status
```

For more information on using communication handles, see form [1700](#), the *PAC Control User's Guide*.

2: Reset the axes

To start configuration, it's a good idea to reset all four axes (0–3).

In an OptoScript block use the PAC Control command Transmit/Receive to send the motion control [Reset command](#).

For example, to reset the axes for board 0, enter the following code using your own com handle and response string variable:

```
Status = TransmitReceiveString(">Reset,0", ComHandleVariable,
RespStringVariable)
```

Also see, “[Entering Commands in OptoScript](#)” on [page 32](#)

For more information on using the Transmit/Receive command, see form [1701](#), the PAC Control Command Reference.

NOTE: It's not necessary to reset with every move.

3: Configure parameters

Next you'll want to configure all of the parameters.

In the following example, the parameters are borrowed from the S-Curve Contouring example included with the motion control example strategies (see ["Using the Example Strategies" on page 24](#)). Only 8 of the parameters are set. The rest have been commented out with `//`.

Example:

```
// Setup Axis 0 for S-Curve Contouring.
nStatus = TransmitReceiveString(">SetAcceleration,0,3,FF",
comMotionModule, sCommandResponse);
nStatus = TransmitReceiveString(">SetDeceleration,0,3,FF",
comMotionModule, sCommandResponse);

nStatus = TransmitReceiveString(">SetActualPosition,0,0,0",
comMotionModule, sCommandResponse);

nStatus = TransmitReceiveString(">SetActualPositionUnits,0,1",
comMotionModule, sCommandResponse);

nStatus = TransmitReceiveString(">SetProfileMode,0,2",
comMotionModule, sCommandResponse);
nStatus = TransmitReceiveString(">SetLimitSwitchMode,0,1",
comMotionModule, sCommandResponse);

nStatus = TransmitReceiveString(">SetSignalSense,0,0800",
comMotionModule, sCommandResponse); //StepOutput Bit 11
nStatus = TransmitReceiveString(">SetJerk,0,2,FFFF",
comMotionModule, sCommandResponse);
```

4: Enable each axis

After configuring the parameters, make sure each axis you are using is enabled by sending the [GetMotorMode](#) command.

For example, for axis 0 send `>GetMotorMode,0`. If the response is 1, the axis is ready. If its 0, troubleshoot the configuration strings used in the previous step.

Example:

```
sVelocity0 = ">SetVelocity,0,";
nVelocity0 = nRPM * 447.392426667; // Look in the User's
Guide to Calculate RPMs, etc.
NumberToHexString((nVelocity0 >> 16) bitand 0xFFFF, sTemp);
sVelocity0 += sTemp; // Append the first data word.
sVelocity0 += Chr(',');
NumberToHexString(nVelocity0 bitand 0xFFFF, sTemp);
sVelocity0 += sTemp; // Append the second data word.
```

```
nStatus = TransmitReceiveString(sVelocity0, comMotionModule,
sCommandResponse);
```

5: Close the communication handle

Finally, close the communication handle.

Example:

```
Close Communication
Communication Handle    comMotionModule
Put Status in           comMoitonModule_status
```

How To Find Home

For many applications it's important to be able to move your device to the home position. To do this, send the SetBreakPointValue and SetBreakPoint commands to enable a breakpoint at home. Then send the device position to a value past the home point. This allows you to rely on the home inputs and the breakpoints to stop the device.

NOTE: Always make sure to load the breakpoint comparison value (SetBreakPointValue command) before setting a new breakpoint condition (SetBreakPoint command). Failure to do so will likely result in unexpected behavior.

Single Axis Example

```
// Set Positions to a value just past home.
nPosition0 = 280000;

sPosition0 = ">SetPosition,0,";
NumberToHexString((nPosition0 >> 16) bitand 0xFFFF, sTemp);
sPosition0 += sTemp; // Append the first data word.
sPosition0 += Chr(',');
NumberToHexString(nPosition0 bitand 0xFFFF, sTemp);
sPosition0 += sTemp; // Append the second data word.
nStatus = TransmitReceiveString(sPosition0,
comMotionModule, sCommandResponse);

// Set Breakpoint 0 setup for signal status
nStatus = TransmitReceiveString(">SetBreakPointValue,0,0,0008,0000",
comMotionModule, sCommandResponse);

//Breakpoint 0, abrupt stop, signal status
nStatus = TransmitReceiveString(">SetBreakPoint,0,0,0A20",
comMotionModule, sCommandResponse)
```

```
//Send the update command that will the axis move
nStatus = TransmitReceiveString(">Update,0", comMotionModule,
sCommandResponse);
```

Multiple Axis Example

For a multi-axis system, multiple homes can be done simultaneously by setting up all of the axes individually and then using the MultiUpdate command instead of the Update command used above.

```
// Set Positions to a value just past home for axis 0.
nPosition0 = 280000;

sPosition0 = ">SetPosition,0,";
NumberToHexString((nPosition0 >> 16) bitand 0xFFFF, sTemp);
sPosition0 += sTemp; // Append the first data word.
sPosition0 += Chr(',');
NumberToHexString(nPosition0 bitand 0xFFFF, sTemp);
sPosition0 += sTemp; // Append the second data word.
nStatus = TransmitReceiveString(sPosition0,
comMotionModule, sCommandResponse);

// Set Breakpoint 0 setup for signal status
nStatus = TransmitReceiveString(">SetBreakPointValue,0,0,0008,0000",
comMotionModule, sCommandResponse);

//Breakpoint 0, abrupt stop, signal status
nStatus = TransmitReceiveString(">SetBreakPoint,0,0,0A20",
comMotionModule, sCommandResponse)

// Set Positions to a value just past home for axis 1.
nPosition1 = -170000;

sPosition1 = ">SetPosition,1,";
NumberToHexString((nPosition1 >> 16) bitand 0xFFFF, sTemp);
sPosition1 += sTemp; // Append the first data word.
sPosition1 += Chr(',');
NumberToHexString(nPosition1 bitand 0xFFFF, sTemp);
sPosition1 += sTemp; // Append the second data word.
nStatus = TransmitReceiveString(sPosition1,
comMotionModule, sCommandResponse);

// Set Breakpoint 1 setup for signal status
```

```

nStatus = TransmitReceiveString(">SetBreakPointValue,1,1,0008,0000",
comMotionModule, sCommandResponse);

//Breakpoint 1, abrupt stop, signal status
nStatus = TransmitReceiveString(">SetBreakPoint,1,1,0A21",
comMotionModule, sCommandResponse)

//Send the update command that will make all the axis move
nStatus = TransmitReceiveString(">MultiUpdate,0,F", comMotionModule,
sCommandResponse);

```

Moving a Set Distance

To move a set distance, set a variable such as "X_MOVE_COUNT" with an integer. In the following example code taken from a strategy for a module test bed, 12,000 is the number of steps from one module to the next on an X-Y table.

```

sPosition0= ">SetPosition,0,";
nPosition0 = X_MOVE_COUNT ; //12000 is the
distance(Steps) between the modules.
NumberToHexString((nPosition0 >> 16) bitand 0xFFFF, sTemp);
sPosition0 += sTemp; // Append the first data word.
sPosition0 += Chr(',');
NumberToHexString(nPosition0 bitand 0xFFFF, sTemp);
sPosition0 += sTemp; // Append the second data word.
nStatus = TransmitReceiveString(sPosition0,
comMotionModule, sCommandResponse);
nStatus = TransmitReceiveString(">Update,0",
comMotionModule, sCommandResponse);

```

The actual move happens when the `>Update, 0` command is executed.

Using a Smooth Start and Smooth Stop

The [SetStopMode command](#) and the breakpoint commands (such as [SetBreakPoint](#)) all have SmoothStop or AbruptStop options.

Set the starting acceleration with the [SetAcceleration command](#). For example,
`>SetAcceleration, 0, 3, FF.`

Host I/O Errors

The motion processor performs a number of checks on the commands sent to it. These checks improve the safety of the motion system by eliminating incorrect command data values. All such checks associated with host I/O commands are referred to as host I/O errors. To determine the error's cause, use the command [GetHostIOError](#). This command also clears both the error code and the I/O error bit in the I/O status read word.

The following I/O error codes may be returned by the [GetHostIOError](#) command.

Code (hex)	Indication	Cause
00	No error	No error condition
01	Magellan reset	Default value of error code on reset or power-up.
02	Invalid instruction	Instruction is not valid in the current context, or an illegal instruction code has been detected.
03	Invalid axis	The axis number contained in the upper bits of the instruction word is not supported by this motion processor.
04	Invalid parameter	The parameter value sent to the motion processor was out of its acceptable range.
05	Trace running	An instruction was issued that would change the state of the tracing mechanism while the trace is running. Instructions which can return this error are <code>SetTraceVariable</code> , <code>SetTraceMode</code> & <code>SetTracePeriod</code> .
06	Reserved	--
07	Block bound exceeded	1. The value sent by <code>SetBufferLength</code> or <code>SetBufferStart</code> would create a memory block which extends beyond the allowed limits of 400h - 7FFFFFFh. 2. Either <code>SetBufferReadIndex</code> or <code>SetBufferWriteIndex</code> sent an index value greater than or equal to the block length.
08	Trace zero	<code>SetTraceStart Immediate</code> was issued, but the length of the trace buffer is currently set to zero.
09	Bad checksum (<i>Serial port only</i>)	The checksum compiled and returned by Magellan does not match the checksum which was sent by the host.
0A	Communication Timeout	1. Make sure your communication handle is pointing to the SNAP-SCM-MCH16. 2. Check the SNAP-SCM-BB4 address, switch S7. Each motion command has an "Axis" parameter that corresponds to a SNAP-SCM-BB4 address. 3. Check the physical link between the SNAP-SCM-MCH16 and SNAP-SCM-BB4.
0B	Negative velocity	An attempt was made to set a negative velocity without the axis being in velocity contouring profile mode.
0C	S-curve change	The axis is currently executing an S-curve profile move and an attempt was made to change the profile parameters. This is not permitted.
0D	Limit event pending	A limit switch event has occurred.
0E	Move into limit	An attempt was made to execute a move without first clearing the limit bit(s) in the event status register.

How To Use the Command Details

Also see, “[Entering Commands in OptoScript](#)” on page 32 and “[Response Format](#)” on page 33.

For each command in Chapter 5, the instruction mnemonic is shown in the command heading at the left. Certain parameters and other data written to the motion processor are buffered. That is, they are not acted upon until the next Update or MultiUpdate command is executed. These parameters are identified by the word **buffered** in the command heading at the right.

The details for each command are as follows:

Syntax The instruction mnemonic and its required arguments are shown with all arguments separated by commas.

Arguments Encoded-field arguments are packed into a single 16-bit data word. The **Name** of the argument is that shown in the generic syntax.

Instance is the mnemonic used to represent the data value. **Encoding** is the value assigned to the field for that instance.

For numeric arguments, the parameter **Value**, the **Type** (signed or unsigned integer) and **Range** of acceptable values are given. Numeric arguments may require one or two data words. For 32-bit arguments, the high-order part is transmitted first.

You must specify the location of the stepper for each command. The number of the stepper motor identifies one of four SNAP-SCM-BB4 breakout boards as follows:

Stepper Motor Location	Breakout Board Address
0 to 3	0
4 to 7	1
8 to B	2
C to F	3

Data Structure This is a graphic representation of the 16-bit words transmitted in the packet: the instruction, which is identified by its name, followed by 1, 2, or 3 data words. Bit numbers are shown directly below each word. For each field in a word, only the high and low bits are shown. For 32-bit numeric data, the high-order bits are numbered from 16 to 31, the low-order bits from 0 to 15.

Argument names are shown in their respective words or fields.

For data words, the direction of transfer-read or write-is shown at the left of the word's diagram.

Unused bits are shaded. All unused bits must be 0 in data words and instructions sent (written) to the motion processor.

Description Describes what the instruction does and any special information relating to the instruction.

Restrictions Describes the circumstances in which the instruction is not valid, that is, when it should not be issued. For example, velocity, acceleration, deceleration, and jerk parameters may not be issued while an S-curve profile is being executed.

OptoScript Example The syntax of the text string entered within the TransmitReceiveString OptoScript command, which is sent to the motion module for conversion to the corresponding PMD C-Motion command for implementation by the motion control processor.

See Also Refers to related instructions.

Entering Commands in OptoScript

A motion control command is entered as a text string in OptoScript using the TransmitReceiveString command, which is the same as Transmit/Receive String in standard PAC Control. This command sends the motion control command to the processor and then waits for a response. For more information on the Transmit/Receive String command, see the *PAC Control Command Reference*, form 1701. For information on motion control strategy examples available on the Opto 22 website, see [“Using the Example Strategies” on page 24](#).

To enter a motion control command, use the > symbol at the beginning of the command and enclose the command in double quotes, as shown in the following example:

Syntax:


TransmitReceiveString(">Command", Communication Handle, Put Result in)

PAC Control command Motion control command Communication Handle Put Result in
 Status = TransmitReceiveString(">SetAcceleration,4,0,3E", ComHandleVariable, RespStringVariable)

For the PAC Control command use TransmitReceiveString. Note that the Put Result in parameter is for the response from the motion control command. The following examples show the SetAcceleration and Get Acceleration commands. Quotation marks are used here because these are string literals rather than string variables.

Example 1: SetAcceleration.

Motion control command:



Communication Handle:




Put Result in:


RespStringVariable If the status byte returns a 00, the command is successful. Any other response indicates an error. See [“Response Format” on page 33](#).

Example 2: Get Acceleration.

Motion control command:



Communication Handle:



For more information on communication handles, see Chapter 10 in the *PAC Control User's Guide*.


Put Result in:

`RespStringVariable`

If the status byte returns a 00, the command is successful. Any other response indicates an error. See "Response Format," below.

Response Format

Command responses are in the following format:



Returned packet examples:

Successful command: `>00, 0123, 4567, 89AB`

Not successful: `>04`

Command Reference

This command reference provides a list of the motion control commands by group, and a detailed explanation of each command listed in alphabetical order.

For an explanation on how to use the information included for each command, [page 31](#).

In This Chapter

- [Commands by Group36](#)
- [Commands in Alphabetical Order38](#)

Commands by Group

The following Magellan™ Motion Processor commands are supported in PAC Control using OptoScript.

Commands	Description
Breakpoints and Interrupts	
ClearInterrupt	Reset interrupt line.
GetInterruptAxis	Get the axes with pending interrupts.
SetBreakPoint, GetBreakPoint	Set/Get breakpoint type.
SetBreakPointValue, GetBreakPointValue	Set/Get breakpoint comparison value.
SetInterruptMask, GetInterruptMask	Set/Get interrupt mask.
Digital Servo Filter	
ClearPositionError	Set position error to 0.
GetPositionError	Get the position error.
SetAutoStopMode, GetAutoStopMode	Set/Get auto stop on position error (on or off).
SetPositionErrorLimit, GetPositionErrorLimit	Set/Get the maximum position error limit.
Encoder	
AdjustActualPosition	Sum the specified offset with the actual encoder position.
GetActualVelocity	Get the actual encoder velocity.
GetCaptureValue	Get the position capture value, and reset the capture.
SetActualPosition, GetActualPosition	Set/Get the actual encoder position.
SetActualPositionUnits, GetActualPositionUnits	Set/Get the unit type returned for the actual encoder position.
SetCaptureSource, GetCaptureSource	Set/Get the capture source (home or index).
SetEncoderModulus, GetEncoderModulus	Set/Get the full scale range of the parallel-word encoder
SetEncoderSource, GetEncoderSource	Set/Get the encoder type.
SetEncoderToStepRatio, GetEncoderToStepRatio	Set/Get encoder count to step ratio.
External RAM	
ReadBuffer	Read a long word value from a buffer memory locations.
SetBufferLength, GetBufferLength	Set/Get the length of a memory buffer.
SetBufferReadIndex, GetBufferReadIndex	Set/Get the buffer read pointer for a particular buffer.
SetBufferStart, GetBufferStart	Set/Get the start location of a memory buffer.
SetBufferWriteIndex, GetBufferWriteIndex	Set/Get the buffer write pointer for a particular buffer.
WriteBuffer	Write a long word value to a buffer memory location.
Motor Output	
SetMotorMode, GetMotorMode	Set/Get motor loop mode.
SetStepRange, GetStepRange	Set/Get the allowable range (in kHz) for step output generation.
Profile Generation	
GetCommandedAcceleration	Get commanded (instantaneous desired) acceleration
GetCommandedPosition	Get commanded (instantaneous desired) position.
GetCommandedVelocity	Get commanded (instantaneous desired) velocity.
MultiUpdate	Forces buffered command values to become active for multiple axes.
SetAcceleration, GetAcceleration	Set/Get acceleration limit.

Commands	Description
SetDeceleration, GetDeceleration	Set/Get deceleration limit.
SetGearMaster, GetGearMaster	Set/Get the electronic gear mode master axis and source (actual or target-based).
SetGearRatio, GetGearRatio	Set/Get commanded electronic gear ratio.
SetJerk, GetJerk	Set/Get jerk limit.
SetPosition, GetPosition	Set/Get the destination position.
SetProfileMode, GetProfileMode	Set/Get the profile mode (S-curve, trapezoidal, velocity-contouring, or electronic gear).
SetStartVelocity, GetStartVelocity	Set/Get start velocity.
SetStopMode, GetStopMode	Set/Get stop command; abrupt, smooth, or none.
SetVelocity, GetVelocity	Set/Get velocity limit.
Update	Forces buffered command values to become active.
ServoLoopControl	
GetTime	Get current chip set time (number of servo loops).
SetAxisMode, GetAxisMode	Set/Get the axis operation mode (enabled or disabled).
SetLimitSwitchMode, GetLimitSwitchMode	Set/Get the limit switch mode (on or off).
SetMotionCompleteMode, GetMotionCompleteMode	Set/Get the motion complete mode (target-based or actual).
SetSampleTime, GetSampleTime	Set/Get servo loop sample time.
SetSettleTime, GetSettleTime	Set/Get the axis-settled time.
SetSettleWindow, GetSettleWindow	Set/Get the settle-window boundary value.
SetTrackingWindow, GetTrackingWindow	Set/Get the tracking window boundary value.
Status Registers and AxisOut Indicator	
GetActivityStatus	Get activity status register.
GetEventStatus	Get event status register.
GetSignalStatus	Get the signal status register.
ResetEventStatus	Reset bits in event status register.
SetAxisOutSource, GetAxisOutSource	Set/Get axis out signal monitor source.
SetSignalSense, GetSignalSense	Set/Get the interpretation of the signal status bits.
Miscellaneous	
NoOperation	Perform no operation.
Reset	Reset the SNAP-SCM-BB4.

Commands in Alphabetical Order

AdjustActualPosition 33	GetJerk 50	SetBufferLength, GetBufferLength 73
ClearInterrupt 34	GetLimitSwitchMode 50	SetBufferReadIndex, GetBufferReadIndex 74
ClearPositionError 35	GetMotionCompleteMode 50	SetBufferStart, GetBufferStart 75
GetAcceleration 35	GetMotorMode 50	SetBufferWriteIndex, GetBufferWriteIndex 76
GetActivityStatus 36	GetPosition 50	SetCaptureSource, GetCaptureSource 77
GetActualPosition 37	GetPositionError 51	SetDeceleration, GetDeceleration 78
GetActualPositionUnits 37	GetPositionErrorLimit 51	SetEncoderModulus, GetEncoderModulus 79
GetActualVelocity 38	GetProfileMode 51	SetEncoderSource, GetEncoderSource 80
GetAutoStopMode 39	GetSampleTime 52	SetEncoderToStepRatio, GetEncoderToStepRatio 81
GetAxisMode 39	GetSettleTime 52	SetGearMaster, GetGearMaster 82
GetAxisOutSource 39	GetSettleWindow 52	SetGearRatio, GetGearRatio 83
GetBreakPoint 39	GetSignalSense 52	SetInterruptMask, GetInterruptMask 85
GetBreakPointValue 39	GetSignalStatus 53	SetJerk, GetJerk 86
GetBufferLength 39	GetStartVelocity 54	SetLimitSwitchMode, GetLimitSwitchMode 87
GetBufferReadIndex 40	GetStepRange 54	SetMotionCompleteMode, GetMotionCompleteMode 88
GetBufferStart 40	GetStopMode 54	SetMotorMode, GetMotorMode 89
GetBufferWriteIndex 40	GetTrackingWindow 54	SetPosition, GetPosition 90
GetCaptureSource 40	GetTime 55	SetPositionErrorLimit, GetPositionErrorLimit 91
GetCaptureValue 41	GetVelocity 55	SetProfileMode, GetProfileMode 92
GetCommandedAcceleration 42	MultiUpdate 56	SetSampleTime, GetSampleTime 93
GetCommandedPosition 43	NoOperation 57	SetSettleTime, GetSettleTime 94
GetCommandedVelocity 44	ReadBuffer 58	SetSettleWindow, GetSettleWindow 95
GetDeceleration 45	Reset 59	SetSignalSense, GetSignalSense 96
GetEncoderModulus 45	ResetEventStatus 61	SetStartVelocity, GetStartVelocity 98
GetEncoderSource 45	SetAcceleration, GetAcceleration 62	SetStepRange, GetStepRange 99
GetEncoderToStepRatio 45	SetActualPosition, GetActualPosition 63	SetStopMode, GetStopMode 100
GetEventStatus 46	SetActualPositionUnits, GetActualPositionUnits 64	SetTrackingWindow, GetTrackingWindow 101
GetGearMaster 47	SetAutoStopMode, GetAutoStopMode 65	SetVelocity, GetVelocity 102
GetGearRatio 47	SetAxisMode, GetAxisMode 66	Update 103
GetHostIOError 48	SetAxisOutSource, GetAxisOutSource 67	WriteBuffer 104
GetInterruptAxis 49	SetBreakPoint, GetBreakPoint 69	
GetInterruptMask 50	SetBreakPointValue, GetBreakPointValue 71	

AdjustActualPosition


Syntax AdjustActualPosition, *axis*, *P1*, *P2*

Arguments

	Type	Range	Board Address		
<i>axis</i>	unsigned 8 bits	0 to 3	0		
		4 to 7	1		
		8 to B	2		
		C to F	3		
	Type	Range	Scaling	Units	
<i>position</i>	signed 32 bits	-231 to 231-1	unity	counts/cycle ² microsteps/cycle	

Data Structure

AdjustActualPosition



Description

The position specified as the parameter to AdjustActualPosition is summed with the actual position register (encoder position) for the specified axis. This has the effect of adding or subtracting an offset to the current actual position. At the same time, the commanded position is replaced by the new actual position value minus the position error. This prevents a servo “bump” when the new axis position is established. The destination position (see [“SetPosition, GetPosition” on page 96](#)) is also modified by this amount so that no trajectory motion will occur when the update instruction is issued. In effect, this instruction establishes a new reference position from which subsequent positions can be calculated. It is commonly used to set a known reference position after a homing procedure. The position error is also zeroed.

AdjustActualPosition takes effect immediately, it is not buffered.

OptoScript Example

```
Status=TransmitReceiveString
(">AdjustActualPosition,4,0,3E",ComHandle,ResponseString)
```

See Also

[GetPositionError](#) (page 57), [GetActualVelocity](#) (page 44), [SetActualPositionUnits](#), [GetActualPositionUnits](#) (page 70), [SetActualPosition](#), [GetActualPosition](#) (page 69)

ClearInterrupt

Syntax ClearInterrupt, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Description ClearInterrupt resets the HostInterrupt signal to its inactive state. If interrupts are still pending, the HostInterrupt line will return to its active state within one chip cycle. Refer to Set/GetSampleTime for information on chip cycle timing (page 99). It is used after an interrupt has been recognized and processed by the host. This command does not affect the event status register. The ResetEventStatus command should be issued prior to the ClearInterrupt command to clear the condition which generated the interrupt. The ClearInterrupt command has no effect if it is executed when no interrupts are pending.

The axis number is not used.

OptoScript Example `Status=TransmitReceiveString
(>ClearInterrupt,0",ComHandle,ResponseString)`

See Also [GetInterruptAxis \(page 55\)](#), [SetInterruptMask](#), [GetInterruptMask \(page 91\)](#), [ResetEventStatus \(page 67\)](#)

ClearPositionError

buffered

Syntax ClearPositionError, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Description ClearPositionError sets the profile's commanded position equal to the actual position (encoder input), thereby clearing the position error for the specified axis. This command can be used when the axis is at rest, or when it is moving.

Restrictions ClearPositionError is a buffered command. The new value set will not take effect until the next Update or MultiUpdate instruction.
This command should not be sent while the chip is executing a move using the S-curve profile mode.

OptoScript Example
 Status=TransmitReceiveString
 (>ClearPositionError,1", ComHandle, ResponseString)

See Also [GetPositionError \(page 57\)](#), [MultiUpdate \(page 62\)](#), [SetPositionErrorLimit](#), [GetPositionErrorLimit \(page 97\)](#)

GetAcceleration


See "[SetAcceleration, GetAcceleration](#)" on page 68.

GetActivityStatus

Syntax GetActivityStatus, *axis*, *P1*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Returned Data	Name	Type
	<i>status</i>	unsigned 32 bits <i>see below</i>



Description GetActivityStatus reads the 16-bit activity status register for the specified axis. Each of the bits in this register continuously indicate the state of the motion processor without any action on the part of the host. There is no direct way to set or clear the state of these bits, since they are controlled by the motion processor.

The following table shows the encoding of the data returned by this command

Name	Bits	Description																				
<i>reserved</i>	6	Not used; may be 0 or 1.																				
<i>reserved</i>	0	Not used; may be 0 or 1.																				
At maximum velocity	1	Set to 1 when the trajectory is at maximum velocity. This bit is determined by the trajectory generator, not the actual encoder velocity.																				
Tracking	2	Set to 1 when the axis is within the tracking window.																				
Current profile mode	3-5	Contains trajectory mode encoded as follows:																				
		<table border="0" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;"><u>bit 5</u></th> <th style="text-align: left; border-bottom: 1px solid black;"><u>bit 4</u></th> <th style="text-align: left; border-bottom: 1px solid black;"><u>bit 3</u></th> <th style="text-align: left; border-bottom: 1px solid black;"><u>Profile Mode</u></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>trapezoidal</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>velocity contouring</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>s-curve</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>electronic gear</td> </tr> </tbody> </table>	<u>bit 5</u>	<u>bit 4</u>	<u>bit 3</u>	<u>Profile Mode</u>	0	0	0	trapezoidal	0	0	1	velocity contouring	0	1	0	s-curve	0	1	1	electronic gear
<u>bit 5</u>	<u>bit 4</u>	<u>bit 3</u>	<u>Profile Mode</u>																			
0	0	0	trapezoidal																			
0	0	1	velocity contouring																			
0	1	0	s-curve																			
0	1	1	electronic gear																			
Axis settled	7	Set to 1 when the axis is settled.																				
Motor on/off	8	Set to 1 when motor mode is on, 0 when off.																				
Position capture	9	Set to 1 when a value has been captured by the high speed position capture hardware but has not yet been read.																				
In-motion	10	Set to 1 when the trajectory generator is executing a profile.																				
In positive limit	11	Set to 1 when the positive limit switch is active.																				
In negative limit	12	Set to 1 when the negative limit switch is active.																				

Name	Bits	Description
Profile segment	13-15	When the profile mode is S-curve, it contains the profile segment number 1-7 while profile is in motion, and contains a value of 0 when the profile is at rest. This field is undefined when using the Trapezoidal and Velocity Contouring profile modes.

**OptoScript
Example**

```
Status=TransmitReceiveString
(">GetActivityStatus,2",ComHandle,ResponseString)
```

See Also

[GetEventStatus](#) (page 52), [GetSignalStatus](#) (page 59)

GetActualPosition

See "[SetActualPosition, GetActualPosition](#)" on page 69.

GetActualPositionUnits


See "[SetActualPositionUnits, GetActualPositionUnits](#)" on page 70.

GetActualVelocity

Syntax GetActualVelocity, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Returned Data	Name	Type	Range	Scaling	Units
	<i>velocity</i>	signed 32 bits	-231 to 231-1	$1/2^{16}$	counts/cycle ²



Description GetActualVelocity reads the value of the velocity for the specified axis. The actual velocity is derived by subtracting the actual position during the previous chip cycle from the actual position for this chip cycle. The result of this subtraction will always be integer because position is always integer. As a result the value returned by GetActualVelocity will always be a multiple of 65,536 since this represents a value of one in the 16.16 number format. The low word is always zero.

This value is the result of the last encoder input, so it will be accurate to within one cycle.

Scaling example: If a value of 1,703,936 is retrieved by the GetActualVelocity command (high word: 01Ah, low word: 0h) this corresponds to a velocity of 1,703,936/65,536 or 26 counts/cycle. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Restrictions The actual velocity is derived by subtracting the actual position during the previous chip cycle from the actual position for this chip cycle. The result of this subtraction will always be integer because position is always integer. As a result the value returned by GetActualVelocity will always be a multiple of 65,536 since this represents a value of one in the 16.16 number format. The low word is always zero.

OptoScript Example `Status=TransmitReceiveString (>GetActualVelocity, 3", ComHandle, ResponseString)`

See Also [GetCommandedVelocity \(page 50\)](#)

GetAutoStopMode

See [“SetAutoStopMode, GetAutoStopMode”](#) on page 71.

GetAxisMode

See [“SetAxisMode, GetAxisMode”](#) on page 72.

GetAxisOutSource

See [“SetAxisOutSource, GetAxisOutSource”](#) on page 73.

GetBreakPoint

See [“SetBreakPoint, GetBreakPoint”](#) on page 75.

GetBreakPointValue

See [“SetBreakPointValue, GetBreakPointValue”](#) on page 77.

GetBufferLength

See [“SetBufferLength, GetBufferLength”](#) on page 79.

GetBufferReadIndex

See [“SetBufferReadIndex, GetBufferReadIndex”](#) on page 80.

GetBufferStart

See [“SetBufferStart, GetBufferStart”](#) on page 81.

GetBufferWriteIndex

See [“SetBufferWriteIndex, GetBufferWriteIndex”](#) on page 82.

GetCaptureSource

See [“SetCaptureSource, GetCaptureSource”](#) on page 83.


GetCaptureValue

Syntax GetCaptureValue, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Type	Range	Scaling	Units
<i>captured position</i>	signed 32 bits	-231 to 231-1	unity	counts microsteps

Data Structure



Description GetCaptureValue returns the contents of the position capture register for the specified axis. This command also resets bit 9 of the activity status register; thus allowing another capture to occur. If actual position units is set to steps, the returned position will be in units of steps.

OptoScript Example

```
Status=TransmitReceiveString
(">GetCaptureValue, 4", ComHandle, ResponseString)
```


See Also [SetCaptureSource](#), [GetCaptureSource](#) (page 83), [SetActualPositionUnits](#), [GetActualPositionUnits](#) (page 70), [GetActivityStatus](#) (page 42)

GetCommandedAcceleration

Syntax GetCommandedAcceleration, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Returned Data	Name	Type	Range	Scaling	Units
	<i>acceleration</i>	signed 32 bits	-231 to 231-1	$1/2^{16}$	counts/cycle ² microsteps/cycle



Description GetCommandedAcceleration returns the commanded acceleration value for the specified axis. Commanded acceleration is the instantaneous acceleration value output by the trajectory generator.

Scaling example: If a value of 114,688 is retrieved using this command then this corresponds to $114,688 / 65,536 = 1.750$ counts/cycle² acceleration value. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

OptoScript Example `Status=TransmitReceiveString (">GetCommandedAcceleration,5", ComHandle, ResponseString)`


See Also [GetCommandedPosition \(page 49\)](#), [GetCommandedVelocity \(page 50\)](#)

GetCommandedPosition

Syntax GetCommandedPosition, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data	Name	Type	Range	Scaling	Units
	<i>position</i>	signed 32 bits	-231 to 231-1	unity	counts microsteps



Description GetCommandedPosition returns the commanded position for the specified axis. Commanded position is the instantaneous position value output by the trajectory generator.

This command functions in all profile modes.

OptoScript Example

```
Status=TransmitReceiveString
(">GetCommandedPosition,6",ComHandle,ResponseString)
```


See Also [GetCommandedAcceleration \(page 48\)](#), [GetCommandedVelocity \(page 50\)](#)

GetCommandedVelocity

Syntax GetCommandedVelocity, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Returned Data	Name	Type	Range	Scaling	Units
	<i>velocity</i>	signed 32 bits	-2 ³¹ to 2 ³¹ -1	1/2 ¹⁶	counts/cycle microsteps/cycle



Description GetCommandedVelocity returns the commanded velocity value for the specified axis. Commanded velocity is the instantaneous velocity value output by the trajectory generator.

Scaling example: If a value of -1,234,567 is retrieved using this command (FFEDh in high word, 2979h in low word) then this corresponds to $-1,234,567/65,536 = -18.8380$ counts/cycle velocity value. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

OptoScript Example `Status=TransmitReceiveString
(">GetCommandedVelocity,7",ComHandle,ResponseString)`

See Also [GetCommandedAcceleration \(page 48\)](#), [GetCommandedPosition \(page 49\)](#)

GetDeceleration

See [“SetDeceleration, GetDeceleration”](#) on page 84.

GetEncoderModulus

See [“SetEncoderModulus, GetEncoderModulus”](#) on page 85.

GetEncoderSource

See [“SetEncoderSource, GetEncoderSource”](#) on page 86.

GetEncoderToStepRatio

See [“SetEncoderToStepRatio, GetEncoderToStepRatio”](#) on page 87.


GetEventStatus

Syntax GetEventStatus, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data

Name	Type
<i>status</i>	unsigned 16 bits <i>see below</i>



Description GetEventStatus reads the event register for the specified axis. All of the bits in this status word are set by the motion processor and cleared by the host. To clear these bits, use the ResetEventStatus command. The following table shows the encoding of the data returned by this command.

Name	Bit(s)	Description
Motion complete	0	Set to 1 when motion has completed. SetMotionCompleteMode determines if this bit is based on the trajectory generator position or the encoder position.
Wrap-around	1	Set to 1 when the actual (encoder) position has wrapped from maximum allowed position to minimum, or vice versa.
Breakpoint 1	2	Set to 1 when breakpoint 1 has been triggered.
Capture received	3	Set to 1 when a position capture has occurred.
Motion error	4	Set to 1 when a motion error has occurred.
In positive limit	5	Set to 1 when the axis has entered a positive limit switch.
In negative limit	6	Set to 1 when the axis has entered a negative limit switch.
Instruction error	7	Set to 1 when an instruction error has occurred.
reserved 8 - 10	8 - 10	Not used; may be 0 or 1.
Commutation error	11	Set to 1 when a commutation error has occurred.
reserved 12 - 13	12 - 13	Not used; may be 0 or 1.
Breakpoint 2	14	Set to 1 when breakpoint 2 has been triggered.
reserved 15	15	Not used; may be 0 or 1.

OptoScript Example

```
Status=TransmitReceiveString
(">GetEventStatus,8",ComHandle,ResponseString)
```

See Also [GetActivityStatus \(page 42\)](#), [GetSignalStatus \(page 59\)](#)

GetGearMaster

See [“SetGearMaster, GetGearMaster”](#) on page 88.

GetGearRatio

See [“SetGearRatio, GetGearRatio”](#) on page 89.


GetHostIOError

Syntax GetHostIOError, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Returned Data	Name	Instance	Encoding
<i>axis mask</i>		None	0
		Axis0mask	1
		Axis1mask	2
		Axis2mask	4
		Axis3mask	8

Name Type Range *error* unsigned 16 bits 0 - Eh



Description GetHostIOError returns the code for the last host I/O error, and then resets the error to zero. Generally, this command is issued only after the instruction error bit in the event status register indicates there was an I/O error. It also resets the HostIOError bit in the I/O status read word to zero. The error codes are encoded as defined below:

Error Code	Encoding
No error	0
Processor Reset	1
Invalid instruction	2
Invalid axis	3
Invalid parameter	4
Trace running	5
reserved	6
Block out of bounds	7
Trace buffer zero	8
Bad serial checksum	9
<i>reserved</i>	Ah
Invalid negative value	Bh
Invalid parameter change	Ch

Error Code	Encoding
Invalid move after limit condition	Dh
Invalid move into limit	Eh

OptoScript Example

```
Status=TransmitReceiveString
(">GetIOHostError,0",ComHandle,ResponseString)
```

See also [GetEventStatus \(page 52\)](#)

GetInterruptAxis

Syntax `GetInterruptAxis, axis`

Arguments *none*

Returned Data

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Instance	Encoding
<i>axis mask</i>	None	0
	Axis0mask	1
	Axis1mask	2
	Axis2mask	4
	Axis3mask	8

Data Structure

GetInterruptAxis



Description `GetInterruptAxis` returns a field which identifies all axes on the breakout board with pending interrupts. Axis numbers are assigned to the low-order four bits of the returned word; bits corresponding to interrupting axes are set to 1. If there are no pending interrupts, the returned word is 0. If any axis has a pending interrupt, the *HostInterrupt* signal will be in an active state.

OptoScript Example

```
Status=TransmitReceiveString
(">GetInterruptAxis,9",ComHandle,ResponseString);
```

See Also [ClearInterrupt \(page 40\)](#), [SetInterruptMask](#), [GetInterruptMask \(page 91\)](#)

GetInterruptMask

See [“SetInterruptMask, GetInterruptMask”](#) on page 91.

GetJerk

See [“SetJerk, GetJerk”](#) on page 92.

GetLimitSwitchMode

See [“SetLimitSwitchMode, GetLimitSwitchMode”](#) on page 93.

GetMotionCompleteMode

See [“SetMotionCompleteMode, GetMotionCompleteMode”](#) on page 94.

GetMotorMode

See [“SetMotorMode, GetMotorMode”](#) on page 95.

GetPosition

See [“SetPosition, GetPosition”](#) on page 96.

GetPositionError

Syntax `GetPositionError, axis`

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data	Name	Type	Range	Scaling	Units
	<i>velocity</i>	signed 32 bits	-231 to 231-1	unity	counts microsteps

Data Structure	GetPositionError		
	First data word		
P1 read	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;"><i>position error</i> (high-order part)</td> </tr> <tr> <td style="text-align: center;">31 16</td> </tr> </table>	<i>position error</i> (high-order part)	31 16
<i>position error</i> (high-order part)			
31 16			
	Second data word		
P2 read	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;"><i>position error</i> (low-order part)</td> </tr> <tr> <td style="text-align: center;">15 0</td> </tr> </table>	<i>position error</i> (low-order part)	15 0
<i>position error</i> (low-order part)			
15 0			

Description `GetPositionError` returns the position error of the specified axis. The error is the difference between the actual position (encoder position) and the commanded position (instantaneous output of the trajectory generator). When used with the motor type set to microstepping, or pulse and direction, the error is defined as the difference between the encoder position (represented in steps), and the commanded position (instantaneous output of the trajectory generator).

OptoScript Example `Status=TransmitReceiveString`
 `(">GetPositionError,9",ComHandle,ResponseString)`

See Also [SetPosition](#), [GetPosition](#) (page 96), [SetPositionErrorLimit](#), [GetPositionErrorLimit](#) (page 97)

GetPositionErrorLimit

See "[SetPositionErrorLimit](#), [GetPositionErrorLimit](#)" on page 97.

GetProfileMode

See "[SetProfileMode](#), [GetProfileMode](#)" on page 98.

GetSampleTime

See [“SetSampleTime, GetSampleTime”](#) on page 99.

GetSettleTime

See [“SetSettleTime, GetSettleTime”](#) on page 100.

GetSettleWindow

See [“SetSettleWindow, GetSettleWindow”](#) on page 101.

GetSignalSense

See [“SetSignalSense, GetSignalSense”](#) on page 102.

GetSignalStatus

Syntax GetSignalStatus, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data

Name	Type
<i>see below</i>	unsigned 16 bits

Data Structure

GetSignalStatus

First data word

P1 read

15	<i>status</i>	0
----	---------------	---

Description GetSignalStatus returns the contents of the signal status register for the specified axis. The signal status register contains the value of the various hardware signals connected to each axis of the motion processor. The value read is combined with the signal sense register (see [“SetSignalSense, GetSignalSense” on page 102](#)) and then returned to the user. For each bit in the Signal Sense register that is set to 1, the corresponding bit in the GetSignalStatus command will be inverted. Therefore, a low signal will be read as 1, and a high signal will be read as a 0. Conversely, for each bit in the signal sense register that is set to 0, the corresponding bit in the GetSignalStatus command is not inverted. Therefore, a low signal will be read as 0, and a high signal will be read as a 1.

All of the bits in the GetSignalStatus command are inputs, except for AxisOut. The value read for this bit is equal to the value output by the axis out mechanism. See [“SetAxisOutSource, GetAxisOutSource” on page 73](#) for more details. The bit definitions are as follows:

Description	Bit Number
Encoder A	0
Encoder B	1
Encoder Index	2
Encoder Home	3
Positive limit	4
Negative limit	5
AxisIn	6
reserved	7–9
AxisOut	10
reserved	11–15

OptoScript Example

```
Status=TransmitReceiveString
(">GetSignalStatus,A",ComHandle,ResponseString)
```

See Also [GetActivityStatus \(page 42\)](#), [GetEventStatus \(page 52\)](#), [SetSignalSense, GetSignalSense \(page 102\)](#)

GetStartVelocity

See [“SetStartVelocity, GetStartVelocity”](#) on page 104.

GetStepRange

See [“SetStepRange, GetStepRange”](#) on page 105.

GetStopMode

See [“SetStopMode, GetStopMode”](#) on page 106.

GetTrackingWindow

See [“SetTrackingWindow, GetTrackingWindow”](#) on page 107.

GetTime

Syntax GetTime, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data	Name	Type	Range	Scaling	Units
	<i>velocity</i>	signed 32 bits	-231 to 231-1	unity	counts

Data Structure	GetTime
	<div style="text-align: center;">First data word</div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px;">P1 read</div> <div style="border: 1px solid black; padding: 2px; margin-left: 5px;"> <i>time</i> (high-order part) </div> <div style="margin-left: 5px;"> <div style="border-top: 1px solid black; width: 100%;"></div> <div style="display: flex; justify-content: space-between; width: 100%;"> 31 16 </div> </div> </div>
	<div style="text-align: center;">Second data word</div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px;">P2 read</div> <div style="border: 1px solid black; padding: 2px; margin-left: 5px;"> <i>time</i> (low-order part) </div> <div style="margin-left: 5px;"> <div style="border-top: 1px solid black; width: 100%;"></div> <div style="display: flex; justify-content: space-between; width: 100%;"> 15 0 </div> </div> </div>

Description GetTime returns the number of cycles which have occurred since the motion processor was last reset.

OptoScript Example Status=TransmitReceiveString (">GetTime,B",ComHandle,ResponseString)

GetVelocity

See [“SetVelocity, GetVelocity”](#) on page 108.

MultiUpdate

Syntax MultiUpdate, *axis*, *P1*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>mask</i>	None	0
	Axis0mask	1
	Axis1mask	2
	Axis2mask	4
	Axis3mask	8

Returned data none



Description MultiUpdate causes an Update to occur on all axes whose corresponding bit is set to 1 in the mask argument. After this command is executed, and for those axes which are selected using the mask, all buffered data parameters are copied into the corresponding run-time registers. The following table shows the buffered commands and variables which are made active as a result of the Update command.

Type	Command
General	ClearPositionError
Trajectory	Acceleration Deceleration GearRatio Jerk Position ProfileMode StopMode Velocity
Servo	DerivativeTime IntegrationLimit Kaff Kd Ki Kp Kvff
Motor	MotorCommand

OptoScript Example `Status=TransmitReceiveString
(">MultiUpdate,B,P1",ComHandle,ResponseString)`

See Also [Update \(page 109\)](#)

NoOperation

Syntax `NoOperation, axis`

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data none

Description The NoOperation command has no effect on the motion processor.


ReadBuffer

Syntax ReadBuffer, *axis*, *P1*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Type	Range
<i>bufferID</i>	unsigned 16 bits	-0 to 31

Returned Data	Name	Type	Range
	<i>data</i>	signed 32 bits	-231 to 231-1



Description ReadBuffer returns the 32-bit contents of the location pointed to by the read buffer index in the specified buffer. After the contents have been read, the read index is incremented by 1; if the result is equal to the buffer length (set by SetBufferLength), the index is reset to 0. The read index is automatically changed at the completion of a trace when in rolling trace mode.

OptoScript Example
 Status=TransmitReceiveString
 (>ReadBuffer, C, P1", ComHandle, ResponseString)

See Also [SetBufferReadIndex](#), [GetBufferReadIndex](#) (page 80), [WriteBuffer](#) (page 110), [SetBufferStart](#), [GetBufferStart](#) (page 81), [SetBufferLength](#), [GetBufferLength](#) (page 79)

Reset

Syntax Reset, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Returned Data none

Description Reset restores the motion processor to its initial condition, setting all motion processor variables to their default values.

Variable Name	Default Value	Variable Name	Default Value
StartVelocity	0	LimitSwitchMode	1
Acceleration	0	MotionCompleteMode	0
ActualPosition	0	MotorBias	0
ActualPositionUnits	0	MotorCommand	0
AutoStopMode	1	MotorLimit	32767
AuxilliaryEncoderSource	0	MotorMode	1
AxisMode	1	OutputMode	-
AxisOutSource	0	PhaseAngle	0
BiQuadCoefficients	0	PhaseCorrectionMode	-
Breakpoint 1	0	PhaseCounts	-
Breakpoint 2	0	PhaseCounts	1
BreakpointValue 1	0	PhaseInitializeMode	0
BreakpointValue 2	0	PhaseInitializeTime	0
BufferLength	0	PhaseOffset	65535
BufferReadIndex	0	PhasePrescaleMode	0
BufferStart	0	Position	0
BufferWriteIndex	0	PositionErrorLimit	65535
CaptureSource	0	ProfileMode	0
CommutationMode	-	PWMFrequency (kHz)	-
Deceleration	0	SampleTime	see notes
DerivativeTime	1	SettleTime	0
EncoderModulus	0	SettleWindow	0
EncoderSource	3	SPIMode	-
EncoderToStepRatio	00010001h	StepRange	1*
EventStatus	1	StepRange	see notes
GearMaster	0	StopMode	0
GearRatio	0	SynchronizationMode	0
GetSignalStatus	800 (hex)	TraceMode	0
IntegrationLimit	0	TracePeriod	1
InterruptMask	0	TraceStart	0
Jerk	0	TraceStop	0
Kaff	0	TraceVariable 1	0

Variable Name	Default Value	Variable Name	Default Value
Kd	0	TraceVariable 2	0
Ki	0	TraceVariable 3	0
Kout	65535	TraceVariable 4	0
Kp	0	TrackingWindow	0
Kvff	0	Velocity	0

*The SNAP-SCM-BB4 has a maximum step range of 100kHz which cannot be changed.

Notes:

- All axes supported by the motion processor are enabled at reset.
- See [“SetSampleTime, GetSampleTime” on page 99](#) for information regarding the default sample time.
- The typical time before the device is ready for communication after a Reset is 20ms.
- The Reset command “axis” parameter selects the board to reset. Axes 0x00-0x03 will reset board 0. Axes 0x04-0x07 will reset board 1. Axes 0x08-0x0B will reset board 2. Axes 0x0C-0x0F will reset board 3. No motion command directly addresses a SNAP-SCM-BB4 by board address. Instead the board address is determined by which axis the command is sent to. See the following examples.

Reset Board 0:

```
"Status=TransmitReceiveString (>Reset, 0", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 1", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 2", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 3", ComHandle, ResponseString) "
```

Reset Board 1:

```
"Status=TransmitReceiveString (>Reset, 4", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 5", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 6", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 7", ComHandle, ResponseString) "
```

Reset Board 2:

```
"Status=TransmitReceiveString (>Reset, 8", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 9", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 10", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 11", ComHandle, ResponseString) "
```

Reset Board 3:

```
"Status=TransmitReceiveString (>Reset, 12", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 13", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 14", ComHandle, ResponseString) "
"Status=TransmitReceiveString (>Reset, 15", ComHandle, ResponseString) "
```

OptoScript Example

```
Status=TransmitReceiveString (>Reset, 0", ComHandle, ResponseString)
```

ResetEventStatus


Syntax ResetEventStatus, *axis*, *P1*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Instance	Encoding
<i>mask</i>	Motion Complete	0001h
	Wrap-Around	0002h
	Breakpoint 1	0004h
	Capture Received	0008h
	Motion Error	0010h
	In positive limit	0020h
	In negative limit	0040h
	Instruction error	0080h
	Commutation error	0800h
	Breakpoint 2	4000h

Returned Data none

Packet Structure



Description ResetEventStatus clears (sets to 0), for the specified axis, each bit in the event status register that has a value of 0 in the mask sent with this command. All other event status register bits (bits which have a mask value of 1) are unaffected.

OptoScript Example

```
Status=TransmitReceiveString
(">ResetEventStatus,D,P1",ComHandle,ResponseString)
```

See Also [GetEventStatus \(page 52\)](#)

SetAcceleration, GetAcceleration

buffered


Syntax SetAcceleration, *axis*, P1, P2
GetAcceleration, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Type	Range	Scaling	Units
<i>acceleration</i>	unsigned 32 bits	0 to 2 ³¹ -1	1/2 ¹⁶	counts/cycle ² microsteps/cycle ²

Data Structure

SetAcceleration



GetAcceleration



Description

SetAcceleration loads the maximum acceleration buffer register for the specified axis. This command is used with the Trapezoidal, Velocity Contouring, and S-curve profiling modes.

GetAcceleration reads the maximum acceleration buffer register.

Scaling example: To load a value of 1.750 counts/cycle² multiply by 65,536 (giving 114,688) and load the resultant number as a 32-bit number, giving 0001 in the high word and C000h in the low word. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Values returned by GetAcceleration must correspondingly be divided by 65,536 to convert to units of counts/cycle² or steps/cycle². See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Restrictions

SetAcceleration may not be issued while an axis is in motion with the S-curve profile.

SetAcceleration is not valid in Electronic Gearing profile mode.

SetAcceleration is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

OptoScript Example

```
Status=TransmitReceiveString
(">SetAcceleration,C,P1,P2",ComHandle,ResponseString)
```

```
Status=TransmitReceiveString
(">GetAcceleration,C",ComHandle,ResponseString)
```

See Also [SetDeceleration, GetDeceleration](#) (page 84), [SetJerk, GetJerk](#) (page 92), [SetPosition, GetPosition](#) (page 96), [SetVelocity, GetVelocity](#) (page 108), [MultiUpdate](#) (page 62), [Update](#) (page 109)

SetActualPosition, GetActualPosition

Syntax SetActualPosition, *axis, P1, P2*
GetActualPosition, *axis*


Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Type	Range	Scaling	Units
<i>position</i>	signed 32 bits	2^{31} to $2^{31}-1$	unity	counts microsteps

Data Structure

SetActualPosition



GetActualPosition



Description SetActualPosition loads the position register (encoder position) for the specified axis. At the same time, the commanded position is replaced by the loaded value minus the position error. This prevents a servo “bump” when the new axis position is established. The destination position (see [“SetPosition, GetPosition” on page 96](#)) is also modified by this amount so that no trajectory motion will occur when the update instruction is issued. In effect, this instruction establishes a new reference position from which subsequent positions can be calculated. It is commonly used to set a known reference position after a homing procedure.

For axes configured as Pulse & Direction or Microstepping motor types, ActualPositionUnits determines if the position is specified and returned in units of counts or steps. Additionally, for these motor types, the position error is zeroed when the SetActualPosition command is sent. SetActualPosition takes effect immediately, it is not buffered. GetActualPosition reads the contents of the encoder’s actual position register. This value will be accurate to within one cycle (as determined by Set/GetSampleTime).

OptoScript Example

```
Status=TransmitReceiveString
(">SetActualPosition,D,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetActualPosition,D",ComHandle,ResponseString)
```

See Also [GetPositionError \(page 57\)](#) [SetActualPositionUnits](#), [GetActualPositionUnits \(page 70\)](#), [AdjustActualPosition \(page 39\)](#)

SetActualPositionUnits, GetActualPositionUnits

Syntax SetActualPositionUnits, *axis*, *P1*
GetActualPositionUnits, *axis*


Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Instance	Encoding
<i>mode</i>	Counts	0
	Steps	1

Data Structure

SetActualPositionUnits



GetActualPositionUnits



Description

SetActualPositionUnits determines the units used by the Set/GetActualPosition, AdjustActualPosition and GetCaptureValue for the specified axis. When set to Counts, position units are in encoder counts. When set to Steps, position units are in steps. The step position is calculated using the ratio as set by the SetEncoderToStepRatio command.

GetActualPositionUnits returns the position units for the specified axis.

OptoScript Example

```
Status=TransmitReceiveString
(">SetActualPositionUnits,E,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetActualPositionUnits,E",ComHandle,ResponseString)
```


See Also [SetActualPosition](#), [GetActualPosition \(page 69\)](#), [SetEncoderToStepRatio](#), [GetEncoderToStepRatio \(page 87\)](#), [AdjustActualPosition \(page 39\)](#), [GetCaptureValue \(page 47\)](#)

SetAutoStopMode, GetAutoStopMode

Syntax SetAutoStopMode, *axis*, *P1*
GetAutoStopMode, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Instance	Encoding
<i>mode</i>	Disable	0
	Enable	1



Description SetAutoStopMode determines the behavior of the specified axis when a motion error occurs. When auto stop is enabled (SetAutoStopMode Enable), the axis goes into open-loop mode when a motion error occurs. When Auto-Stop is disabled (SetAutoStopMode Disable), the axis is not affected by a motion error.

GetAutoStopMode returns the state of the Auto-Stop mode.

Restrictions When the encoder source is set to none (SetEncoderSource None), setting the auto stop mode to Enable will not stop motion in the event that the position error limit is exceeded.

OptoScript Example

```
Status=TransmitReceiveString
(">SetAutoStopMode,F,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetAutoStopMode,F",ComHandle,ResponseString)
```

See Also [GetEventStatus \(page 52\)](#), [SetPositionErrorLimit](#), [GetPositionErrorLimit \(page 97\)](#)

SetAxisMode, GetAxisMode

Syntax SetAxisMode, *axis*, *P1*
GetAxisMode, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>mode</i>	Off	0
	On	1

Data Structure



Description SetAxisMode enables (On) or disables (Off) the specified axis. A disabled axis will not respond to profile or other motion commands.

GetAxisMode returns the mode of the specified axis.

Restrictions Disabled axes do not provide encoder feedback. If it is desired that an axis provide encoder feedback even though no profiling or servo control is to be used, the axis must be left enabled.

OptoScript Example

```
Status=TransmitReceiveString
(">SetAxisMode,0,P1",ComHandle,ResponseString)
Status=TransmitReceiveString (">GetAxisMode,0",ComHandle,ResponseString)
```

SetAxisOutSource, GetAxisOutSource

Syntax SetAxisOutSource, *axis*, *P1*
GetAxisOutSource, *axis*

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3


NOTE: The source axis must be on the same SNAP-SCM-BB4 as the axis argument.

Name	Type	Range	Board Address
<i>sourceAxis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Instance	Encoding
<i>bit</i>	<i>see below</i>	0 to 15
<i>register</i>	Disabled EventStatus ActivityStatus SignalStatus	0 1 2 3

Data Structure

SetAxisMode



GetAxisMode



Description

SetAxisOutSource maps the specified bit of the specified status register of axis to the AxisOut pin for the specified axis. The state of the AxisOut pin will thereafter track the state of bit. If register is absent (encoding of 0), bit is ignored, and the specified AxisOut pin is, in effect, turned off (inactive). When the AxisOutSource is set to disabled, the AxisOut signal can be set high or low using SetSignalSense bit 10.

GetAxisOutSource returns the mapping of the AxisOut pin of axis.

The following table shows the corresponding value for combinations of *bit* and *register*.

bit	event status register	activity status register	signal status register
0	Motion complete	Phasing initialized	Encoder A
1	Wrap-around	At maximum velocity	Encoder B
2	Breakpoint 1	Tracking	Encoder index

bit	event status register	activity status register	signal status register
3	Position capture		Home
4	Motion error		Positive limit
5	In positive limit		Negative limit
6	In negative limit		AxisIn
7	Instruction error	Axis settled	Hall sensor 1
8		Motor on/off	Hall sensor 2
9		Position capture	Hall sensor 3
0Ah		In motion	
0Bh	Commutation error	In positive limit	
0Ch		In negative limit	
0Dh			
0Eh	Breakpoint 2		
0Fh			

**OptoScript
Example**

```
Status=TransmitReceiveString
(">SetAxisOutSource,1,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetAxisOutSource,1",ComHandle,ResponseString)
```

See Also

[SetSignalSense, GetSignalSense \(page 102\)](#)

SetBreakPoint, GetBreakPoint


Syntax SetBreakPoint, *axis*, *P1*, *P2*
GetBreakPoint, *axis*, *P1*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


NOTE: The source axis must be on the same SNAP-SCM-BB4 as the axis argument.

Name	Instance	Encoding
<i>breakpointID</i>	Breakpoint1	0
	Breakpoint2	1
<i>sourceAxis</i>	Axis0	0
	Axis1	1
	Axis2	2
	Axis3	3
<i>action</i>	(none)	0
	Update	1
	AbruptStop	2
	SmoothStop	3
	MotorOff	4
<i>trigger</i>	(none)	0
	GreaterOrEqualCommandedPosition	1
	LesserOrEqualCommandedPosition	2
	GreaterOrEqualActualPosition	3
	LesserOrEqualActualPosition	4
	CommandedPositionCrossed	5
	ActualPositionCrossed	6
	Time	7
	EventStatus	8
	ActivityStatus	9
SignalStatus	Ah	

SetBreakPoint



GetBreakPoint



Description SetBreakPoint establishes a breakpoint for the specified axis to be triggered by a condition or event on sourceAxis, which may be the same as or different from axis. Up to two concurrent breakpoints can be set for each axis, each of which may have its own breakpoint type and comparison value. The breakpointID field specifies which breakpoint the SetBreakPoint and GetBreakPoint commands will address.

The six Position breakpoints and the Time breakpoint are threshold-triggered; the breakpoint occurs when the indicated value reaches or crosses a threshold. The Status breakpoints are level-triggered; the breakpoint occurs when a specific bit or combination of bits in the indicated status register changes state. Thresholds and bit specifications are both set by the SetBreakPointValue instruction.

action determines what the motion processor does when the breakpoint occurs, as follows:

Action	Resultant command sequence
None	No action
Update	Update axis
AbruptStop	The profile executes an abrupt stop
SmoothStop	The profile executes a smooth stop
MotorOff	SetMotorMode axis, Off

GetBreakPoint returns the trigger, action, and axis for the specified breakpoint (0 or 1) of the indicated axis. When a breakpoint occurs, the trigger value will be reset to none. The CommandedPositionCrossed and the ActualPositionCrossed triggers are converted to one of the Position trigger types 1-4; depending on the current position when the command is issued.

Restrictions Always load the breakpoint comparison value (SetBreakPointValue command) before setting a new breakpoint condition (SetBreakPoint command). Failure to do so will likely result in unexpected behavior.

OptoScript Example

```
Status=TransmitReceiveString
(">SetBreakPoint,2,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetBreakPoint,2,P1",ComHandle,ResponseString)
```

See Also [SetBreakPointValue](#), [GetBreakPointValue](#) (page 77)

SetBreakPointValue, GetBreakPointValue

Syntax SetBreakPointValue, *axis*, *P1*, *P2*, *P3*
GetBreakPointValue, *axis*, *P1*

Arguments



axis	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>breakpointID</i>	Breakpoint 1	0
	Breakpoint 2	1



value see below

Data Structure

SetBreakPointValue



GetBreakPointValue



Description

SetBreakPointValue sets the breakpoint comparison value for the specified axis. For the position and time breakpoints, this is a threshold comparison value.

The value parameter is interpreted according to the trigger condition for the selected breakpoint; see “SetBreakPoint, GetBreakPoint” on page 75. The data format for each trigger condition is as follows:

Breakpoint Trigger	Value Type	Range	Units
GreaterOrEqualCommandedPosition	signed 32-bit	-2^{31} to $2^{31}-1$	counts

Breakpoint Trigger	Value Type	Range	Units
LesserOrEqualCommandedPosition	signed 32-bit	-2^{31} to $2^{31}-1$	counts
GreaterOrEqualActualPosition	signed 32-bit	-2^{31} to $2^{31}-1$	counts
LesserOrEqualActualPosition	signed 32-bit	-2^{31} to $2^{31}-1$	counts
CommandedPositionCrossed	signed 32-bit	-2^{31} to $2^{31}-1$	counts
ActualPositionCrossed	signed 32-bit	-2^{31} to $2^{31}-1$	counts
Time	unsigned 32-bit	0 to $2^{31}-1$	cycles
EventStatus	2 word mask	-	boolean status values
ActivityStatus	2 word mask	-	boolean status values
SignalStatus	2 word mask	-	boolean status values

For level-triggered breakpoints, the high-order part of value is the selection mask, and the low-order word is the sense mask. For each selection bit that is set to 1, the corresponding bit of the specified status register is conditioned to cause a breakpoint when it changes state. The sense-mask bit determines which state causes the break. If it is 1, the corresponding status-register bit will cause a break when it is set to 1. If it is 0, the status-register bit will cause a break when it is set to 0.

For example assume it is desired that the breakpoint type will be set to EventStatus and that a breakpoint should be recognized whenever the motion complete bit (bit 0 of event status register) is set to 1, or the commutation error bit (bit 11 of event status register) is set to 0. In this situation the high and low words for value would be high word: 0x801 (hex) and low word: 1.

GetBreakPointValue returns the breakpoint value for the specified breakpointID.

Two completely separate breakpoints are supported, each of which may have its own breakpoint type and comparison value. The breakpointID field specifies which breakpoint the SetBreakPointValue and GetBreakPointValue commands will address.

Restrictions Always load the breakpoint comparison value (SetBreakPointValue command) before setting a new breakpoint condition (SetBreakPoint command). Failure to do so will likely result in unexpected behavior.

OptoScript Example

```
Status=TransmitReceiveString
(">SetBreakPointValue,3,P1,P2,P3",ComHandle,ResponseString)

Status=TransmitReceiveString
(">GetBreakPointValue,3,P1",ComHandle,ResponseString)
```

See Also [SetBreakPoint](#), [GetBreakPoint](#) (page 75)

SetBufferLength, GetBufferLength

Syntax SetBufferLength, *axis*, *P1*, *P2*, *P3*
GetBufferLength, *axis*, *P1*




Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3




Name	Type	Range
<i>bufferID</i>	unsigned 16 bits	0 to 31
<i>length</i>	unsigned 32 bits	1 to 230 - 1

Data Structure

SetBufferLength



GetBufferLength



Description SetBufferLength sets the length, in number of 32-bit elements, of the buffer in the memory block identified by *bufferID*.

NOTE: SetBufferLength resets the buffers read and write indexes to 0.

GetBufferLength returns the length of the specified buffer.

OptoScript Example

```
Status=TransmitReceiveString
(">SetBufferLength, 4, P1, P2, P3", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetBufferLength, 4, P1", ComHandle, ResponseString)
```

See Also [SetBufferReadIndex](#), [GetBufferReadIndex](#) (page 80), [SetBufferStart](#), [GetBufferStart](#) (page 81), [SetBufferWriteIndex](#), [GetBufferWriteIndex](#) (page 82)

SetBufferReadIndex, GetBufferReadIndex


Syntax SetBufferReadIndex, *axis, P1, P2, P3*
GetBufferReadIndex, *axis, P1*

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Type	Range	Scaling	Units
<i>bufferID</i>	unsigned 16 bits	0 to 31	unity	-
<i>index</i>	unsigned 32 bits	0 to buffer	unity length - 1	double words

Data Structure



Description SetBufferReadIndex sets the address of the read index for the specified bufferID. GetBufferReadIndex returns the current read index for the specified bufferID.

Restrictions If the read index is set to an address beyond the length of the buffer, the command will not be executed and will return host I/O error code 7, buffer bound exceeded.

OptoScript Example

```
Status=TransmitReceiveString
(">SetBufferReadIndex, 5, P1, P2, P3", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetBufferReadIndex, 5, P1", ComHandle, ResponseString)
```

See Also [SetBufferLength](#), [GetBufferLength](#) (page 79), [SetBufferStart](#), [GetBufferStart](#) (page 81), [SetBufferWriteIndex](#), [GetBufferWriteIndex](#) (page 82)

SetBufferStart, GetBufferStart



Syntax SetBufferStart, *axis*, *P1*, *P2*, *P3*
GetBufferStart, *axis*, *P1*

Arguments




	Type	Range	Board Address		
<i>axis</i>	unsigned 8 bits	0 to 3	0		
		4 to 7	1		
		8 to B	2		
		C to F	3		
Name	Type	Range	Scaling	Units	
<i>bufferID</i>	unsigned 16 bits	0 to 31	unity	-	
<i>address</i>	unsigned 32 bits	0 to $2^{31} - 1$	unity	double words	

Data Structure

SetBufferStart



GetBufferStart



Description SetBufferStart sets the starting address for the specified buffer, in double-words, of the buffer in the memory block identified by *bufferID*.

NOTE: SetBufferStart resets the buffers read and write indexes to 0.

GetBufferStart returns the starting address for the specified *bufferID*.

OptoScript Example

```
Status=TransmitReceiveString
(">SetBufferStart, 6, P1, P2, P3", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetBufferStart, 6, P1", ComHandle, ResponseString)
```

See Also [SetBufferLength](#), [GetBufferLength](#) (page 79), [SetBufferReadIndex](#), [GetBufferReadIndex](#) (page 80), [SetBufferWriteIndex](#), [GetBufferWriteIndex](#) (page 82)

SetBufferWriteIndex, GetBufferWriteIndex

Syntax SetBufferWriteIndex, *axis*, *P1*, *P2*, *P3*
GetBufferWriteIndex, *axis*, *P1*

Arguments


	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Type	Range	Scaling	Units
<i>bufferID</i>	unsigned 16 bits	0 to 31	unity	-
<i>index</i>	unsigned 32 bits	0 to buffer length - 1	unity	double words


Description SetBufferWriteIndex sets the write index for the specified *bufferID*.
GetBufferWriteIndex returns the write index for the specified *bufferID*.

Data Structure

SetBufferWriteIndex



GetBufferWriteIndex



OptoScript Example

```
Status=TransmitReceiveString
(">SetBufferWriteIndex, 7, P1, P2, P3", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetBufferWriteIndex, 7, P1", ComHandle, ResponseString)
```

See Also



[SetBufferLength](#), [GetBufferLength](#) (page 79), [SetBufferReadIndex](#), [GetBufferReadIndex](#) (page 80), [SetBufferStart](#), [GetBufferStart](#) (page 81)

SetCaptureSource, GetCaptureSource

Syntax SetCaptureSource, *axis*, *P1*
GetCaptureSource, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3
	Name	Instance	Encoding
	<i>source</i>	Index Home	0 1

Data Structure



Description SetCaptureSource determines which of two encoder signals, Index or Home, is used to trigger the high-speed capture of the actual axis position for the specified axis.
GetCaptureSource returns the capture signal source for the selected axis.

OptoScript Example

```
Status=TransmitReceiveString
(">SetCaptureSource, 2, P1", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetCaptureSource, 2", ComHandle, ResponseString)
```

See Also [GetCaptureValue \(page 47\)](#)

SetDeceleration, GetDeceleration

buffered

Syntax SetDeceleration, *axis*, *P1*, *P2*
GetDeceleration, *axis*



Arguments

axis	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Scaling	Units
<i>deceleration</i>	unsigned 32 bits	0 to 2 ³¹ -1	1/2 ¹⁶	counts/cycle ² microsteps/cycle ²

Data Structure

SetDeceleration



GetDeceleration



Description

SetDeceleration loads the maximum deceleration buffer register for the specified axis. GetDeceleration returns the value of the maximum deceleration buffer.

Scaling example: To load a value of 1.750 counts/cycle² multiply by 65,536 (giving 114,688) and load the resultant number as a 32-bit number, giving 0001 in the high word and C000h in the low word. Retrieved numbers (GetDeceleration) must correspondingly be divided by 65,536 to convert to units of counts/cycle² or steps/cycle². See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Restrictions

This is a buffered command. The new value set will not take effect until the next Update or MultiUpdate instruction is entered.

These commands are used with the Trapezoidal and Velocity Contouring profile modes. They are not used with the Electronic Gearing or S-curve profile mode.

NOTE: If deceleration is set to zero, then the value specified for acceleration (SetAcceleration) will automatically be used to set the magnitude of deceleration.

OptoScript Example

```
Status=TransmitReceiveString
(">SetDeceleration, 5, P1, P2", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetDeceleration, 5", ComHandle, ResponseString)
```

See Also

[SetAcceleration](#), [GetAcceleration](#) (page 68), [SetPosition](#), [GetPosition](#) (page 96), [SetVelocity](#), [GetVelocity](#) (page 108), [MultiUpdate](#) (page 62), [Update](#) (page 109)

SetEncoderModulus, GetEncoderModulus

Syntax

```
SetEncoderModulus, axis, P1
GetEncoderModulus, axis
```

Arguments

axis	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Type	Range	Scaling	Units
<i>modulus</i>	unsigned 16bits	0 to 2 ¹⁶ -1	unity	counts

Data Structure**SetEncoderModulus****GetEncoderModulus****Description**

SetEncoderModulus sets the parallel word range for the specified *axis* when parallel-word feedback is used. *Modulus* determines the range of the connected device. For multi-turn systems, this value is used to determine when a position wrap condition has occurred. The value provided should be one half of the actual range of the axis. For example if the parallel-word input is used with a linear potentiometer connected to an external A/D (Analog to Digital converter) which has 12 bits of resolution, then the total range is 4,096 and a value of 2,048 should be loaded with this command. GetEncoderModulus returns the encoder modulus.

Restrictions

A value for encoder modulus is only required when the encoder source is set to parallel.

OptoScript Example

```
Status=TransmitReceiveString
(">SetEncoderModulus, 5, P1", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetEncoderModulus, 5", ComHandle, ResponseString)
```

See Also


[SetEncoderSource](#), [GetEncoderSource](#) (page 86)

SetEncoderSource, GetEncoderSource

Syntax SetEncoderSource, *axis*, *P1*
GetEncoderSource, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Instance	Encoding
<i>source</i>	Incremental	0
	reserved	1
	None	3
	Loopback	4



Description SetEncoderSource sets the type of feedback (Incremental, None, or Loopback) for the specified axis. When incremental is selected the motion processor expects A and B quadrature signals to be input at the quad A/B axis inputs. When Loopback is selected, the step output is internally fed back into the quad counters. This allows for position capture of the step position when a physical encoder is not present.

GetEncoderSource returns the code for the current type of feedback.

OptoScript Example

```
Status=TransmitReceiveString
(">SetEncoderSource, 7, P1", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetEncoderSource, 7", ComHandle, ResponseString)
```

SetEncoderToStepRatio, GetEncoderToStepRatio

Syntax SetEncoderToStepRatio, *axis*, *P1*, *P2*
GetEncoderToStepRatio, *axis*



Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Scaling	Units
<i>counts</i>	unsigned 16 bits	0 to $2^{15}-1$	unity	counts
<i>steps</i>	unsigned 16 bits	0 to $2^{15}-1$	unity	microsteps

Data Structure

SetEncoderToStepRatio



GetEncoderToStepRatio



Description

SetEncoderToStepRatio sets the ratio of the number of encoder counts to the number of output steps per motor rotation used by the motion processor to convert encoder counts into steps. Counts is the number of encoder counts per full rotation of the motor. Steps is the number of steps output by the motion processor per full rotation of the motor. Since this command sets a ratio, the parameters do not have to be for a full rotation as long as they correctly represent the encoder count to step ratio.

GetEncoderToStepRatio returns the ratio of the number of encoder counts to the number of output steps per motor rotation.

OptoScript Example

```
Status=TransmitReceiveString
(">SetEncoderToStepRatio,8,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetEncoderToStepRatio,8",ComHandle,ResponseString)
```

See Also

[SetActualPositionUnits](#), [GetActualPositionUnits](#) (page 70)

SetGearMaster, GetGearMaster

Syntax SetGearMaster, *axis*, *P1*
GetGearMaster, *axis*



Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

NOTE: The master axis must be on the same SNAP-SCM-BB4 as the axis argument.

Name	Type	Range
<i>masterAxis</i>	unsigned 8 bits	0
		1
		2
		3

Name	Instance	Encoding
<i>source</i>	Actual	0
	Commanded	1

Data Structure



Description

SetGearMaster establishes the slave (*axis*) and master (*masterAxis*) axes for the electronic-gearing profile, and sets the source, Actual or Commanded, of the master axis position data to be used. The *masterAxis* determines the axis that will drive the slave axis. Both the slave and the master axes must be enabled (SetAxisMode command). The source determines whether the master axis' commanded position as determined by the trajectory generator will be used to drive the slave axis, or whether the master axis' encoder position will be used to drive the slave. GetGearMaster returns the value for the geared axes and position source.

OptoScript Example

```
Status=TransmitReceiveString
(">SetGearMaster, A, P1", ComHandle, ResponseString)
Status=TransmitReceiveString
(">GetGearMaster, A", ComHandle, ResponseString)
```

See Also [SetGearRatio](#), [GetGearRatio](#) (page 89)

SetGearRatio, GetGearRatio





buffered

Syntax SetGearRatio, *slaveAxis*, *P1*, *P2*
GetGearRatio, *slaveAxis*

Arguments

	Type	Range	Board Address
<i>slaveaxis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3

Name	Type	Range	Scaling	Units
<i>ratio</i>	signed 32 bits	-2^{31} to $2^{31}-1$	$1/2^{16}$	SlaveCts/MasterCts

Data Structure**SetGearRatio****GetGearRatio****Description**

SetGearRatio sets the ratio between the master and slave axes for the electronic gearing profile for the current axis. Positive ratios cause the slave to move in the same direction as the master, negative ratios in the opposite direction. The specified ratio has a unity scaling of 65,536.

GetGearRatio returns the gear ratio set for the specified slave axis.

Scaling examples:

Ratio Value	Resultant Ratio
-32,768	.5 negative slave counts for each positive master count
1,000,000	15.259 positive slave counts for each positive master count
123 .0018	positive slave counts for each positive master count

Restrictions

This is a buffered command. The new value set will not take effect until the next Update or MultiUpdate instruction is entered.

**OptoScript
Example**

```
Status=TransmitReceiveString  
(">SetGearRatio,B,P1,P2",ComHandle,ResponseString)  
Status=TransmitReceiveString (">GetGearRatio,B",ComHandle,ResponseString)
```

See Also

[SetGearMaster](#), [GetGearMaster \(page 88\)](#), [MultiUpdate \(page 62\)](#), [Update \(page 109\)](#)

SetInterruptMask, GetInterruptMask

Syntax SetInterruptMask, *axis*, *P1*
GetInterruptMask, *axis*

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Instance	Encoding
<i>mask</i>	Motion complete	0001h
	Wrap-around	0002h
	Breakpoint 1	0004h
	Capture received	0008h
	Motion error	0010h
	In positive limit	0020h
	In negative limit	0040h
	Instruction error	0080h
	Commutation error	0800h
	Breakpoint 2	4000h

Data Structure

SetInterruptMask



GetInterruptMask



Description

SetInterruptMask determines which bits in the event status register of the specified axis will cause a host interrupt. For each interrupt mask bit that is set to 1, the corresponding event status register bit will cause an interrupt when that status register bit goes active (is set to 1). Interrupt mask bits set to 0 will not generate interrupts.

GetInterruptMask returns the mask for the specified axis.

Example: The interrupt mask value 28h will generate an interrupt when either the “in positive limit” bit or the “capture received” bit of the event status register goes active (set to 1).

OptoScript Example

```
Status=TransmitReceiveString
(">SetInterruptMask,C,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetInterruptMask,C",ComHandle,ResponseString)
```

See Also

[ClearInterrupt](#) (page 40), [GetInterruptAxis](#) (page 55)

SetJerk, GetJerk

buffered

Syntax SetJerk, *axis*, *P1*, *P2*
GetJerk, *axis*



Arguments

axis	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Scaling	Units
<i>jerk</i>	unsigned 32 bits	0 to 2 ³¹ -1	1/2 ³²	counts/cycle ³ microsteps/cycle ³

Data Structure

SetJerk



GetJerk



Description

SetJerk loads the jerk register in the parameter buffer for the specified axis.

GetJerk reads the contents of the Jerk register.

Scaling example: To load a jerk value (rate of change of acceleration) of 0.012345 counts/cycle³ (or steps/cycle³) multiply by 2³² or 4,294,967,296. In this example this gives a value to load of 53,021,371 (decimal) which corresponds to a high word of 0329h and a low word of 0ABBh when loading each word in hexadecimal. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Restrictions

SetJerk is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

This command is used only with the S-curve profile mode. It is not used with the trapezoidal, velocity contouring, or electronic gear profile modes.

OptoScript Example

```
Status=TransmitReceiveString
(">SetJerk,D,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString(">GetJerk,D",ComHandle,ResponseString)
```

See Also [SetAcceleration](#), [GetAcceleration](#) (page 68), [SetDeceleration](#), [GetDeceleration](#) (page 84), [SetPosition](#), [GetPosition](#) (page 96), [SetVelocity](#), [GetVelocity](#) (page 108), [MultiUpdate](#) (page 62), [Update](#) (page 109)

SetLimitSwitchMode, GetLimitSwitchMode

Syntax `SetLimitSwitchMode, axis, P1`
`GetLimitSwitchMode, axis`

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Instance	Encoding
<i>mode</i>	Off	0
	On	1

Data Structure

SetLimitSwitchMode



GetLimitSwitchMode



Description `SetLimitSwitchMode` enables (On) or disables (Off) limit-switch sensing for the specified axis. When the mode is enabled, the axis will cause the corresponding limit-switch bits in the event status register and activity status register to be set when it enters either the positive or negative limit switches and the axis will be brought to an abrupt stop. When it is disabled, the status bits are not set, and the axis is not stopped, regardless of whether or not the axis is in a limit switch.

`GetLimitSwitchMode` returns the value for the state of the limit-sensing mode.

OptoScript Example

```
Status=TransmitReceiveString
(">SetLimitSwitchMode,1,P1",ComHandle,ResponseString)

Status=TransmitReceiveString
(">GetLimitSwitchMode,1",ComHandle,ResponseString)
```


See Also [GetActivityStatus](#) (page 42), [GetEventStatus](#) (page 52)

SetMotionCompleteMode, GetMotionCompleteMode

Syntax SetMotionCompleteMode, *axis*, *P1*
 GetMotionCompleteMode, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>mode</i>	commanded	0
	actual	1



Description SetMotionCompleteMode establishes the source for the comparison which determines the motion complete status for the specified axis. When set to commanded mode the motion is considered complete when the profile velocity reaches zero and no further motion will occur without an additional host command. This mode is unaffected by the actual encoder location.

When set to actual mode the motion complete bit will be set when the above condition is true, and when the actual encoder position has been within the settle window (SetSettleWindow command) for the number of cycles specified by the SetSettleTime command. The settle timer is started at zero at the end of the trajectory profile motion, so at a minimum a delay of SettleTime cycles will occur after the trajectory profile motion is complete.

GetMotionCompleteMode returns the value for the motion-complete mode.

OptoScript Example

```
Status=TransmitReceiveString
(">SetMotionCompleteMode,2,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetMotionCompleteMode,2",ComHandle,ResponseString)
```


See Also [SetSettleTime](#), [GetSettleTime \(page 100\)](#), [SetSettleWindow](#), [GetSettleWindow \(page 101\)](#)

SetMotorMode, GetMotorMode

Syntax SetMotorMode, *axis*, *P1*
GetMotorMode, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3 4 to 7 8 to B C to F	0 1 2 3
Name	Instance	Encoding	
<i>mode</i>	Off On	0 1	

Data Structure



Description

SetMotorMode determines the mode of motor operation. When set to On, several events take place. For step motor and microstepping axes, the trajectory generator controls the motor output. For all motor types, when the encoder source (Set/GetEncoderSource) is set to incremental or parallel, the position error is cleared; equivalent to a ClearPositionError command.

When the motor mode is set to Off, the axis is in open-loop mode, and is controlled by commands placed directly into the motor output register by the host. Setting the motor mode to Off also resets the trajectory generator, bringing any active motion to an abrupt stop. In addition, the maximum velocity (Set/GetVelocity) is set to zero. On axes configured for step motor and microstepping motor types, the step generator is switched off when the motor mode is set to Off. The following table shows the motor output source for each motor type and mode.

Motor type	Motor mode	Motor output source
Pulse & direction; microstepping	Off	N/A
	On	Trajectory generator

GetMotorMode returns the value of the motor mode.

OptoScript Example

```
Status=TransmitReceiveString
(">SetMotorMode,3,P1",ComHandle,ResponseString)
Status=TransmitReceiveString(">GetMotorMode,3",ComHandle,ResponseString)
```

See Also [GetActivityStatus \(page 42\)](#)

SetPosition, GetPosition

buffered

Syntax *SetPosition, axis, P1, P2*
 GetPosition, axis



Arguments

axis	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Scaling	Units
<i>position</i>	signed 32 bits	-2^{31} to $2^{31}-1$	unity	counts microsteps

Data Structure

SetPosition



GetPosition



Description *SetPosition* specifies the trajectory destination of the specified axis. It is used in the Trapezoidal and S-curve profile modes.

GetPosition reads the contents of the buffered position register.

Restrictions *SetPosition* is a buffered command. The value set using this command will not take effect until the next *Update* or *MultiUpdate* instruction.

OptoScript Example

```
Status=TransmitReceiveString
(">SetPosition,5,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString (">GetPosition,5",ComHandle,ResponseString)
```

See Also [SetAcceleration](#), [GetAcceleration](#) (page 68), [SetDeceleration](#), [GetDeceleration](#) (page 84), [SetJerk](#), [GetJerk](#) (page 92), [SetVelocity](#), [GetVelocity](#) (page 108), [MultiUpdate](#) (page 62), [Update](#) (page 109)

SetPositionErrorLimit, GetPositionErrorLimit

Syntax SetPositionErrorLimit, *axis*, *P1*, *P2*
GetPositionErrorLimit, *axis*



Arguments

<i>axis</i>	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Scaling	Units
<i>limit</i>	unsigned 32 bits	0 to $2^{31}-1$	unity	counts

Data Structure

SetPositionErrorLimit



GetPositionErrorLimit



Description

SetPositionErrorLimit sets the absolute value of the maximum position error allowable by the motion processor for the specified axis. If the position error exceeds this limit, a motion error occurs. Such a motion error may or may not cause the axis to stop moving depending on the value set using the SetAutoStopMode command.

GetPositionErrorLimit returns the value of the position error limit.

OptoScript Example

```
Status=TransmitReceiveString
(">SetPositionErrorLimit,6,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetPositionErrorLimit,6",ComHandle,ResponseString)
```

See Also

[GetPositionError](#) (page 57), [SetActualPosition](#), [GetActualPosition](#) (page 69), [SetPosition](#), [GetPosition](#) (page 96)

SetProfileMode, GetProfileMode

buffered

Syntax SetProfileMode, *axis*, *P1*
GetProfileMode, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>profile</i>	Trapezoidal	0
	Velocity contouring	1
	S-curve	2
	Electronic gear	3



Description SetProfileMode sets the profile mode for the specified axis.
GetProfileMode returns the contents of the buffered profile-mode register for the specified axis.

Restrictions SetProfileMode is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

OptoScript Example
 Status=TransmitReceiveString
 (>SetProfileMode, 7, P1", ComHandle, ResponseString)

See Also [MultiUpdate \(page 62\)](#), [Update \(page 109\)](#)

SetSampleTime, GetSampleTime

Syntax SetSampleTime, *axis*, *P1*, *P2*
GetSampleTime, *axis*



Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Units
<i>time</i>	unsigned 32 bits	51 to 2^{20}	microseconds

Data Structure

SetSampleTime



GetSampleTime



Description

SetSampleTime sets the time basis for the motion processor. This time basis determines the trajectory update rate for all motor types as well.

The time value is expressed in microseconds. The motion processor hardware can adjust the cycle time only in increments of 51.2 microseconds; the time value passed to this command will be rounded up to the nearest increment of this base value.

Minimum cycle time depends on the number of enabled axes as follows:

# enabled axes	minimum cycle time	cycle time w/ trace capture	time per axis	maximum cycle frequency
1	51.2 μ s	102.4 μ s	51.2 μ s / 102.4 μ s	19.53 KHz (9.76 w/ trace capture)
2	153.6 μ s	153.6 μ s	76.8 μ s	6.51 KHz
3	204.8 μ s	204.8 μ s	68.3 μ s	4.88 KHz
4	256 μ s	256 μ s	64 μ s	3.91 KHz

Using the trace feature on single axis products with the sample time set to 51.2µs will result in unexpected behavior.

GetSampleTime returns the value of the sample time.

Restrictions

This command affects the cycle time for all axes on a given SNAP-SCM-BB4.

This command cannot be used to set a sample time lower than the required minimum cycle time for the current configuration. Attempting to do so will set the sample time to the required minimum cycle time as specified in the previous table.

OptoScript Example

```
Status=TransmitReceiveString
(">SetSampleTime,P1,P2,ComHandle,ResponseString)
Status=TransmitReceiveString (">GetSampleTime,ComHandle,ResponseString)
```

SetSettleTime, GetSettleTime

Syntax

SetSettleTime, *axis*, *P1*
GetSettleTime, *axis*


Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Type	Range	Scaling	Units
<i>time</i>	unsigned 16 bits	0 to 2 ¹⁵ -1	unity	cycles

Data Structure

SetSettleTime



GetSettleTime



Description

SetSettleTime sets the time, in number of cycles, that the specified axis must remain within the settle window before the axis-settled indicator in the activity status register is set.

GetSettleTime returns the value of the settle time for the specified axis.

OptoScript Example

```
Status=TransmitReceiveString
(">SetSettleTime,8,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetSettleTime,8",ComHandle,ResponseString)
```

See Also

[SetMotionCompleteMode](#), [GetMotionCompleteMode](#) (page 94), [SetSettleWindow](#), [GetSettleWindow](#) (page 101), [GetActivityStatus](#) (page 42)

SetSettleWindow, GetSettleWindow

Syntax SetSettleWindow, *axis*, *P1*
GetSettleWindow, *axis*


Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Type	Range	Scaling	Units
<i>window</i>	unsigned 16 bits	0 to $2^{16}-1$	unity	cycles

Data Structure

SetSettleWindow



GetSettleWindow



Description

SetSettleWindow sets the position range within which the specified axis must remain for the duration specified by SetSettleTime before the axis-settled indicator in the activity status register is set.

GetSettleWindow returns the value of the settle window.

OptoScript Example

```
Status=TransmitReceiveString
(">SetSettleWindow,A,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetSettleWindow,A",ComHandle,ResponseString)
```

See Also

[SetMotionCompleteMode](#), [GetMotionCompleteMode](#) (page 94), [SetSettleTime](#), [GetSettleTime](#) (page 100), [GetActivityStatus](#) (page 42)

SetSignalSense, GetSignalSense


Syntax SetSignalSense, *axis*, *P1*
GetSignalSense, *axis*

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Indicator	Encoding	Bit Number
<i>mask</i>	QuadA	0001h	0
	QuadB	0002h	1
	Index	0004h	2
	Home	0008h	3
	PosLimit	0010h	4
	NegLimit	0020h	5
	AxisIn	0040h	6
	reserved	0080h	7
	reserved	0100h	8
	reserved	0200h	9
	AxisOut	0400h	10
	Pulse	0800h	11
	Direction	1000h	12
	reserved		13 - 15

Data Structure



Description

SetSignalSense establishes the sense of the corresponding bits of the signal status register, with the addition of StepOutput and MotorDirection, for the specified axis. For all input signals, the input is inverted if the corresponding sense bit is one; otherwise it is not inverted.

For encoder index/home: if the sense bit is 1, a capture will occur on a low-to-high signal transition. Otherwise, a capture will occur on a high-to-low transition.

For positive and negative limit: if the sense bit is 1, an over-travel condition will occur if the signal is high. Otherwise, an over-travel condition will occur when the signal is low.

The AxisOut signal is inverted if the sense bit is set to one; otherwise it is not inverted.

When the StepOutput bit is set to 1, a step will be generated by the motion processor with a low-to-high transition on the Pulse signal. Otherwise, a step will be generated by the motion processor with a high-to-low transition on the Pulse signal.

Setting the MotorDirection bit has the effect of swapping the sense of positive and negative motor movement.

GetSignalSense returns the value of the signal sense mask.

Restrictions Inverting the encoder A or B signal may prevent the index capture mechanism from operating correctly.

OptoScript Example

```
Status=TransmitReceiveString
(">SetSignalSense,B,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetSignalSense,B",ComHandle,ResponseString)
```

See Also [GetSignalStatus \(page 59\)](#)

SetStartVelocity, GetStartVelocity

Syntax SetStartVelocity, *axis*, *P1*, *P2*
GetStartVelocity, *axis*


Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Type	Range	Scaling	Units
<i>velocity</i>	unsigned 32 bits	0 to 2 ³¹ -1	1/2 ¹⁶	counts/cycle microsteps/cycle

Data Structure

SetStartVelocity



GetStartVelocity



Description

SetStartVelocity loads the starting velocity register for the specified axis. The start velocity is the instantaneous velocity at the start and at the end of the profile.

GetStartVelocity reads the value of the starting velocity register.

Scaling example: To load a starting velocity value of 1.750 counts/cycle multiply by 65,536 (giving 114,688) and load the resultant number as a 32-bit number, giving 0001 in the high word and C000h in the low word. Values returned by GetStartVelocity must correspondingly be divided by 65,536 to convert them to units of counts/cycle. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Restrictions

StartVelocity is only used in the Velocity Contouring and Trapezoidal profile modes.

OptoScript Example

```
Status=TransmitReceiveString
(">SetStartVelocity,C,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetStartVelocity,C,P1",ComHandle,ResponseString)
```

See Also

[SetVelocity, GetVelocity \(page 108\)](#), [SetAcceleration, GetAcceleration \(page 68\)](#), [SetDeceleration, GetDeceleration \(page 84\)](#), [SetPosition, GetPosition \(page 96\)](#)

SetStepRange, GetStepRange

Syntax SetStepRange, *axis*, *P1*
GetStepRange, *axis*

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>frequency</i>	5 MHz	1
	625 kHz	4
	156.25 kHz	6
	39.062 kHz	8

Data Structure

SetStepRange



GetStepRange



Description

SetStepRange sets the maximum pulse rate frequency for the specified axis. For example, if the desired maximum pulse rate is 200,000 pulses/second, the command SetStepRange 4 should be issued.

GetStepRange returns the maximum pulse rate frequency for the specified axis.

OptoScript Example

```
Status=TransmitReceiveString
(">SetStepRange,D,P1",ComHandle,ResponseString)
Status=TransmitReceiveString(">GetStepRange,D",ComHandle,ResponseString)
```


SetStopMode, GetStopMode

buffered

Syntax SetStopMode, *axis*, *P1*
GetStopMode, *axis*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Instance	Encoding
<i>mode</i>	Disabled	0
	AbruptStop	1
	SmoothStop	2



Description SetStopMode stops the specified axis. The available stop modes are AbruptStop, which instantly (without any deceleration phase) stops the axis, SmoothStop which uses the programmed deceleration value and profile shape for the current profile mode to stop the axis, or Disabled, which is generally used to turn off a previously issued set stop command.

NOTE: After an Update, a buffered stop command (SetStopMode command) will reset to the Disabled condition. In other words, if the command SetStopMode is followed by an Update command and then by a GetStopMode command, the retrieved stop mode will be Disabled.

GetStopMode returns the value of the stop mode.

Restrictions SmoothStop mode is not available in the Electronic gear profile mode.
SetStopMode is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

OptoScript Example

```
Status=TransmitReceiveString
(">SetStopMode,E,P1",ComHandle,ResponseString)
Status=TransmitReceiveString (">GetStopMode,E",ComHandle,ResponseString)
```

See Also [MultiUpdate \(page 62\)](#), [Update \(page 109\)](#)

SetTrackingWindow, GetTrackingWindow

Syntax SetTrackingWindow, *axis*, *P1*
GetTrackingWindow, *axis*


Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3


Name	Type	Range	Scaling	Units
<i>window</i>	unsigned 16 bits	0 to $2^{16}-1$	unity	counts

Data Structure

SetTrackingWindow



GetTrackingWindow



Description

SetTrackingWindow sets boundaries for the position error of the specified axis. If the absolute value of the position error exceeds the tracking window, the tracking indicator (bit 2 of the activity status register) is set to 0. When the position error returns to within the window, the tracking indicator is set to 1.

GetTrackingWindow returns the value of the tracking window.

OptoScript Example

```
Status=TransmitReceiveString
(">SetTrackingWindow,F,P1",ComHandle,ResponseString)
Status=TransmitReceiveString
(">GetTrackingWindow,F",ComHandle,ResponseString)
```

See Also

[GetActivityStatus \(page 42\)](#), [SetActualPosition, GetActualPosition \(page 69\)](#)

SetVelocity, GetVelocity

buffered

Syntax SetVelocity, *axis, P1, P2*
GetVelocity, *axis*,



Arguments

axis	Type	Range	Board Address
	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3



Name	Type	Range	Scaling	Units
<i>velocity</i>	signed 32 bits	-2^{31} to $2^{31}-1$	$1/2^{16}$	counts/cycle microsteps/cycle

Data Structure

SetVelocity



GetVelocity



Description

SetVelocity loads the maximum velocity buffer register for the specified axis.

GetVelocity returns the contents of the maximum velocity buffer register.

Scaling example: To load a velocity value of 1.750 counts/cycle, multiply by 65,536 (giving 114,688) and load the resultant number as a 32-bit number; giving 0001 in the high word and C000h in the low word. Numbers returned by GetVelocity must correspondingly be divided by 65,536 to convert to units of counts/cycle. See [“SNAP-SCM-MCH16 Conversion Formulas” on page 111](#).

Restrictions

SetVelocity may not be issued while an axis is in motion with the S-curve profile.

SetVelocity is not valid in Electronic Gear profile mode.

The velocity cannot be negative, except in the VelocityContouring profile mode.

SetVelocity is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

OptoScript Example

```
Status=TransmitReceiveString
(">SetVelocity,0,P1,P2",ComHandle,ResponseString)
Status=TransmitReceiveString (">GetVelocity,0",ComHandle,ResponseString)
```

See Also

[SetAcceleration, GetAcceleration \(page 68\)](#), [SetDeceleration, GetDeceleration \(page 84\)](#), [SetJerk, GetJerk \(page 92\)](#), [SetPosition, GetPosition \(page 96\)](#), [MultiUpdate \(page 62\)](#), [Update \(page 109\)](#)

Update

Syntax Update, *axis*

Arguments

	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Description

Update causes all buffered data parameters to be copied into the corresponding run-time registers on the specified axis.

The following table shows the buffered commands and variables which are made active as a result of the Update command.

Type	Command
General	ClearPositionError
Trajectory	Acceleration Deceleration GearRatio Jerk Position ProfileMode StopMode Velocity
Motor	MotorCommand

OptoScript Example

```
Status=TransmitReceiveString (">Update,1",ComHandle,ResponseString)
```

See Also

[MultiUpdate \(page 62\)](#)

WriteBuffer


Syntax WriteBuffer, *axis*, *P1*, *P2*, *P3*

Arguments	Type	Range	Board Address
<i>axis</i>	unsigned 8 bits	0 to 3	0
		4 to 7	1
		8 to B	2
		C to F	3

Name	Type	Range
<i>bufferID</i>	unsigned 16 bits	0 to 31
<i>value</i>	signed 32 bits	-2 ³¹ to 2 ³¹ -1

Data Structure

WriteBuffer



Description WriteBuffer writes the 32-bit value into the location pointed to by the write buffer index in the specified buffer. After the contents have been written, the write index is incremented by 1. If the result is equal to the buffer length (set by SetBufferLength), the index is reset to 0.

OptoScript Example
 Status=TransmitReceiveString
 (>WriteBuffer, 2, 4, 0, 3E", ComHandle, ResponseString)

See Also [ReadBuffer \(page 64\)](#), [SetBufferWriteIndex](#), [GetBufferWriteIndex \(page 82\)](#)

SNAP-SCM-MCH16 Conversion Formulas

OPTO 22

Use the table on the next page to convert Counts/Cycle used by some of the motion commands.

<p>GetActualVelocity, GetCommandedAcceleration, GetCommandedVelocity, SetAcceleration, GetAcceleration, SetDeceleration, GetDeceleration, SetStartVelocity, GetStartVelocity, SetVelocity, GetVelocity</p>	<p>Revolutions/Hour</p>	<p>Revolutions/Minute</p>	<p>Revolutions/Second</p>	<p>Pulses/Second</p>	<p>Pulses/Cycle</p>	<p>Counts/Pulse</p>	<p>Counts/Cycle</p>	<p>% Error</p>
				$\frac{320 \text{ Pulses}}{\text{Second}} * \frac{0.000256 \text{ Seconds}}{\text{Cycle}} = \frac{65536 \text{ Counts}}{\text{Pulse}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{65536 \text{ Counts}}{\text{Pulse}}$	$\frac{5368 \text{ Counts}}{\text{Cycle}}$	-0.013208
			$\frac{0.2 \text{ Revolutions}}{\text{Second}}$	$\frac{1600 \text{ Pulses}}{\text{Revolution}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{65536 \text{ Counts}}{\text{Pulse}}$	$\frac{5368 \text{ Counts}}{\text{Cycle}}$	-0.013208
		$\frac{12 \text{ Revolutions}}{\text{Minute}}$	$\frac{1 \text{ Minute}}{60 \text{ Seconds}}$	$\frac{1600 \text{ Pulses}}{\text{Revolution}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{65536 \text{ Counts}}{\text{Pulse}}$	$\frac{5368 \text{ Counts}}{\text{Cycle}}$	-0.013208
	$\frac{720 \text{ Revolutions}}{\text{Hour}}$	$\frac{1 \text{ Hour}}{60 \text{ Minute}}$	$\frac{1 \text{ Minute}}{60 \text{ Seconds}}$	$\frac{1600 \text{ Pulses}}{\text{Revolution}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{65536 \text{ Counts}}{\text{Pulse}}$	$\frac{5368 \text{ Counts}}{\text{Cycle}}$	-0.013208
			$\frac{0.02 \text{ Revolutions}}{\text{Second}}$	$\frac{1600 \text{ Pulses}}{\text{Revolution}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{4294967296 \text{ Counts}}{\text{Pulse}}$	$\frac{35184372 \text{ Counts}}{\text{Cycle}}$	$-2.52E-07$
SetJerk		$\frac{1.2 \text{ Revolutions}}{\text{Minute}}$	$\frac{1 \text{ Minute}}{60 \text{ Seconds}}$	$\frac{1600 \text{ Pulses}}{\text{Revolution}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{4294967296 \text{ Counts}}{\text{Pulse}}$	$\frac{35184372 \text{ Counts}}{\text{Cycle}}$	$-2.52E-07$
	$\frac{72 \text{ Revolutions}}{\text{Hour}}$	$\frac{1 \text{ Hour}}{60 \text{ Minute}}$	$\frac{1 \text{ Minute}}{60 \text{ Seconds}}$	$\frac{1600 \text{ Pulses}}{\text{Revolution}}$	$\frac{0.000256 \text{ Seconds}}{\text{Cycle}}$	$\frac{4294967296 \text{ Counts}}{\text{Pulse}}$	$\frac{35184372 \text{ Counts}}{\text{Cycle}}$	$-2.52E-07$

The number of pulses per revolution depends on your Driver/Amplifier. This is how many pulses are required to complete one revolution.

Seconds/Cycle is configurable with the SetSampleTime command. Must be divisible by 51.2µS. Minimum value depends on number of axes enabled.