

## TUNING A PID CONTROL LOOP TECHNICAL NOTE

### INTRODUCTION

If you only use PID control loops now and then, or if you are looking for a less-math-more-visual way to tune your PID loop, then this technical note and our [online graphical tuner](http://www.opto22.com) can help you.


- The [online graphical tuner](http://www.opto22.com) is located at: <http://www.opto22.com>. The tuner calculates the values for PID control loop elements (P, I, D, and scan rate) based on data you enter. It's an easy way to get very close to functional tuning for your real-world process PID. Note that the tuner is optimized for Opto 22's Velocity Type C and similar algorithms.
- This technical note reviews the elements of a PID loop and walks you through using the online tuner. It gives you additional background to supplement the online tuner, but it does not discuss details of the theory or methods of tuning your loop. (Information on theory and methods is available from other sources online.)

Let's start by reviewing what a PID control loop is. Then we'll walk step by step through tuning a PID loop using the online tuner and the open-loop or reaction curve tuning method.

#### What is a PID control loop?

A PID control loop is a mathematical formula that monitors a *process variable* (typically a sensor input), compares it to a *setpoint*, and calculates an *output* to correct any error between that setpoint and the current process variable. The output is a result of proportional, integral, and derivative calculations done at a set rate, for example, once per second.

Here is a block diagram showing broadly how the signal flows through a PID loop.




At the scan time, the sensor input is compared to the setpoint, and an error (the difference between them) is produced. This error is plugged into a mathematical formula with the P, I, and D components, and the result becomes the output that is then applied to the process. The sensor input is again compared to the setpoint, and the loop repeats.

Two common examples of a PID control loop are a car's cruise control and a room thermostat.

- **Cruise control.** When you click the Set button on the car's cruise control, you are requesting the current vehicle speed to be the setpoint. The necessary accelerator pedal movement to maintain this speed will be calculated by the car's PID loop controller.

The loop controller measures the vehicle road speed, determines the positive or negative error from the setpoint, and sees how quickly it is approaching or departing from that setpoint. The result is that either more or less accelerator is applied to the engine.



- **Room thermostat.** In the case of the room thermostat, the temperature is measured and compared to the desired setpoint. Either heating or cooling will be activated, depending on the sign of the error.

### Tuning the loop

To be most effective, each PID loop must be tuned. Tuning makes sure that the PID output (the controlled variable) moves the PID input (the process variable) to the desired setpoint as quickly as possible with minimum overshoot, and then holds that setpoint steady with minimal changes in the output.

In the case of the car's cruise control, we want to make sure the speed does not vary around the setpoint, because if it does, the car's occupants could get motion sickness when the car constantly speeds up and slows down. In the case of the room thermostat, we do not want the room temperature to swing around the setpoint, as the occupants will be uncomfortable as they switch from feeling too cool to feeling too warm. Tuning solves these problems.

Before we dive into tuning the loop, let's take a moment to review a few of the key parts of the PID loop.

#### Proportional

The *proportional* component of the PID calculation (sometimes called *gain* or *error term*) looks only at the difference between the setpoint and the process variable (input). The output signal is a proportional response to this error. Depending on the formula used in the PID controller, increasing the proportional value will speed up the response of the PID loop. Excessive values will put the process into oscillation; even larger values could cause the system to oscillate out of control.

### Integral

The *integral* component sums the output error over time. The integral value is linked to the scan rate of the PID loop. The function of the integral value is to reduce the steady state error to zero. An effect called *integral windup* can occur when the value of the integral saturates the PID controller and the error signal cannot be driven to zero.

Some PID formulas use an inverted integral.

### Derivative

The *derivative* component looks at the rate of change in the output and reduces that rate of change if the output moves too fast. Increasing this value will cause the output to react in very small increments; if increments are too small, the derivative can cause the loop to become sensitive to noise. Often loops can be tuned satisfactorily with no derivative at all.

### Direction of output

Depending on the nature of the process, the direction of output may be the same as or opposite to the direction of the input. You'll need to make sure the output direction is correct for your application.

- In some applications the direction of output is the same as the direction of input (increment/increment, or decrement/decrement).
- In others, the direction of output is the opposite of the direction of input (increment/decrement, or vice versa). This is called a *reverse acting* PID control loop.

In the case of our car cruise control, we need to make sure that when the vehicle approaches a hill and the road speed drops below the setpoint, the PID loop directs the accelerator to apply more power to the engine. In this case, a decrement in the input (road speed) causes an increment to the output (accelerator).

In the case of our heating/cooling system, the thermostat provides the input (the controlled variable) as temperature. There are two PID loop controllers, one for the heating valve and one for the cooling valve. Each has a different setpoint, to ensure that you do not have both valves open at the same time.

In the case of heating, an increase in the room temperature means the PID needs to close the heating valve. Less heating water flows through the valve, so the room cools down. This is an increment on the input that causes a decrement on the output. In the case of cooling, the same increase in room temperature needs to cause an increment in the cooling water valve; this is an increment on the input causing an increment on the output.

PID controllers have different ways of changing the direction of output. Check your PID loop manual or formula to determine the correct way to set the output direction.

### Loop dead time

The amount of time it takes the process to react to a change in the input is called the *loop dead time*. This time delay is a combination of factors, starting with the process itself, the location of the sensors, and any filtering (hardware or software) that may be installed.

For example, moving the temperature sensor physically closer to the output actuator may reduce the loop dead time, but you must take care that the sensor still measures the process accurately. You have to find a balance between the loop dead time and accuracy.

### Scan rate

How often the PID calculation is performed is called the *scan rate*, and scan rate is a very important aspect of configuring the PID loop. If the formula is performed too seldom, you won't be able to control the process; if performed too frequently, the loop might be hard to tune.

Generally the PID scan rate should be at least four times faster than the loop dead time, but it can be as high as 10 times faster. The shorter the loop dead time, the faster your scan rate should be.

At all times keep in mind the speed limits, if any, of your input and output devices, both sensors and actuators. There's no point in scanning faster than they can update.

Since the PID calculation is only performed at the scan rate, be aware that the output will remain static until the next scan. This is why it's important to correctly set the scan rate period, so the output will react to the input in a timely manner.

## PID tuning methods

### P and PI tuning

- **P tuning**—It is possible to “tune” a process using just the proportional value. The problem is that there will be a steady state offset between the process variable and the setpoint. The process will simply never reach the setpoint—but it will be under control.
- **PI tuning**—Some PID loop controllers only offer the option of PI (proportional and integral) tuning. The addition of the integral value removes the steady state offset and ensures that the process settles on the setpoint (once the controller is tuned correctly).

### PID tuning

Complete **PID tuning** is the best way and the usual offering of most PID controllers. The addition of the derivative ensures that the loop is not too overly reactive during any sudden process or setpoint changes.

There are several methods for complete PID tuning. Arguably the most popular are trial and error, reaction curve closed loop (sometimes called infinite oscillation), and reaction curve open loop (sometimes called step response).

For obvious reasons we don't recommend trial and error. Your time is too valuable for that.

The reaction curve closed-loop method is a possibility, but it requires putting the process into a state of oscillation. If not done with a great deal of care, it can easily result in the process being damaged by the oscillations.

So for this technical note and the online tutorial, we're using the reaction curve open loop method, specifically the Ziegler-Nichols Reaction Curve (Ziegler-Nichols Open-Loop) tuning method. This method works well for Opto 22 Velocity Type C and similar algorithms.


This method can be trial-run several times, starting with very small steps in output, thus keeping the process under control while observing the changes in the steps. For most processes, this is a safer method of determining the required tuning parameters.

## TUNING A LOOP USING THE ZIEGLER-NICHOLS OPEN-LOOP METHOD

Here are some limitations to be aware of when using this method of tuning.

- First, the process response time should be around twice the loop dead time. In other words, this method works well to tune most temperature and some pressure processes, but it will not be as useful on slower flow or very dynamic processes, for example a process where the dead loop and response curve are similar in length. Likewise it will be less effective if you have a very long loop dead time, for example HVAC in a large conference room or hall.
- Second, depending on your PID loop controller formula, you may need to invert the integral value that is calculated for you. Check your formula or manual for that information.

- Third, an important part of the tuning method is that the process must self-stabilize for a given change in output.
- And last, critical to this tuning method is that your loop controller software is capable of producing a graph similar to the one below, so you can print out or take a screenshot of the output (controlled variable) step change with the resulting input (process variable) curve.



## Using the online tuner to tune your PID control loop

Tuning PID control loops is not easy, and you must calculate each loop individually. But our [online graphical PID tuner](#) gives you an easier way to calculate a functional loop.

Start by opening a web browser and navigating to: <http://www.opto22.com>

### Graphical PID Control Loop Tuner

PID
An example
What you need
Step 1
Step 2
Step 3
Step 4
Step 5
Step 6
Step 7
Step 8

PID

A PID control loop is (typically) a mathematical calculation that measures a process **input**, compares it to a desired **setpoint**, and applies an **output** designed to match the setpoint as closely as possible.

The output is derived from three values: proportional, integral, and derivative. This calculation is repeated at a set time interval called a scan time, usually in seconds.

You can use a common PID algorithm for nearly any process by selecting numerical values that determine the behavior of proportional, integral, and derivative calculations.

Then you'll need to **tune** each PID control loop to determine the values for proportional, integral, and derivative that will achieve the ideal performance for your individual process.

(Period at which the input is compared to the setpoint and output is adjusted.)

### In the tuner

You'll notice that the first three black or red buttons at the top of the tuner very briefly cover the background that this paper covers in more detail.

The last eight red buttons are the steps you'll follow to enter values from your process and have the tuner calculate P, I, D, and scan rate for your loop.

### Tuning procedure

If you already have some rough tuning values for your PID loop, make a note of them. If not, don't worry; we start with the loop in manual. In either case the procedure is the same: we step the process from one steady state to a higher steady state, and capture the curve of the process in a graph that can be printed out on paper.

Use the first step in the tuner as a guide for the response curve graph that you require. If the curve of the process overruns the time scale of your graph the first time, reset the process, extend the time scale, and step the process again. Or if the process is very responsive and the resulting curve is too compact to measure, reset the process and speed up the graph.

You may need to take a few trial runs at generating a nice clean curve on paper, but as you gain experience in performing this tuning method, you will be faster at getting it right the first time.

### Follow the steps

1. Click the red Step 1 button. Put the PID loop into manual and set the output to a nonzero value. You may need to test this a few times to see what a good low output value is. Again, do not use zero. Try to use a value of at least 10%. For example, with HVAC try a value around 20%. Wait for the process to settle into a steady state. In the tuner, enter the control variable lower and upper values—that is, the output value that you stepped from and the value you stepped to.
2. Watch the controlled variable react to that step change in the process, and wait for the process to settle into a steady state. In the tuner, click the red Step 2 button and enter the upper and lower values of the controlled variable. Remember, you need to wait till the process has settled into a steady state. Use the image in the tuner as a guide of how the curve should look.
3. Click the Step 3 button in the tuner. On your printout, measure the distance between the lower steady state of the controlled variable and upper steady state. Enter the distance between the two states into the tuner. The amount of change in the controlled variable as a result of the step change is used to calculate the P or gain term. Hint: while not required, you may find it easier to use millimeters rather than decimal inches as the distance units.
4. Click the Step 4 button. Press the button in the tuner to have it calculate the 63.2% point on the curve. The answer is given in a height from the lower steady state. Measure this height on your printout and mark the point on the curve. Drop a vertical line down from this point on the curve.
5. Click Step 5. Measure on your printout how long it took the process to change from its lower steady state to the 63.2% point on the curve. In the tuner, enter the distance you measured. This distance will be converted to time in the next step so that we can determine the loop time constant. This is the amount of time that it took the input to move from its lower steady state to the 63.2% point of the input curve. This time tells us how dynamic the process is and is an important part of the Integral value calculation.
6. Click Step 6. On your graph, measure the distance between two known points of time. In the tuner, enter the time (in seconds) from the graph and enter the distance you measured. Again, while not required, you may find it easier to use millimeters rather than decimal inches as the distance units.

- Click Step 7. To help calculate the PID controller scan rate, measure the distance between the step change in the output and the change in the input.  
This is the process loop dead time, that is, the amount of time it takes the process to react to a change. Dead time is an important part of understanding how frequently you should set the PID controller to perform its loop calculation. The online tuner calculates a scan rate that is four times faster than the loop dead time you enter. See "Scan rate" on page 3.
- Click Step 8. Press the "Calculate tuning" button and write down the results.  
The tuner now has all the data it needs to calculate the P, I and D values for you and to suggest a scan rate. If you want to understand the process that the tuner uses to compute those numbers, check the "Show calculation" box.

### Graphical PID Control Loop Tuner

PID An example What you need Step 1 Step 2 Step 3 Step 4 Step 5 Step 6 Step 7 Step 8

Step 8

All values are carried over from previous steps, so all you need to do is scroll down and press the "Calculate tuning" button.

Boom! There are your P, I, and D values. It's a thing of beauty.

Some tweaking may be required, but for the most part, you will be in the ballpark.

CV high:

CV low:

PV high:

PV low:

PV change on paper:

**Calculate 63.2% change**

Find this value on your graph: 22.68

Start of the change in input to the

63.2% point:

Time scale in time units:  seconds

Time scale on paper:

Dead time: Enter the distance between the step change and the response:

Scan time: 0.815 seconds

**Calculate tuning**  Show calculation

P-Tune: 1.333  
I-Tune: 0.067  
D-Tune: 0.016

Find conversion factor:  $73 / 14 = 5.214$

Calculate Loop Time Constant (LTC) from change in x:  $21 / 5.214 = 4.027$  LTC

Open Loop Gain (OLG) from change in Y value:  $60 / 80 = 0.75$  OLG

Inverse of OLG becomes the P-tuning parameter:  $1 / 0.75 = 1.333$  P-tuning parameter

Calculate Integral from Loop Time Constant:  $4.027 / 60 = 0.067$  I-tuning parameter

Calculate Derivative from Integral:  $0.067 / 4 = 0.016$  D-tuning parameter

Calculated values for P, I, and D

Check this box to show the tuner's calculations

Tuner's calculations

Keep in mind that these numbers may still need some fine tuning; but since they are derived from the process itself, they should be very close to functional.

## ADDITIONAL RESOURCES

This technical note provided a brief review of the major parts of a PID control loop, looked at one method to gather the necessary data from the process, and walked you through using our online graphical tuner to calculate the P, I, and D terms and scan rate to bring a process under control using a PID loop.

Here is some additional information online you may find helpful:

- Reaction curve tuning example from the Wisconsin Technical College System (WTCS): <https://www.wisc-online.com/learn/technical/process-control/ele4508/reaction-curve-tuning-example>
- Animated graphic that shows what happens when you adjust the P, I, and D terms in your PID control loop: [https://en.wikipedia.org/wiki/PID\\_controller#/media/File:PID\\_Compensation\\_Animated.gif](https://en.wikipedia.org/wiki/PID_controller#/media/File:PID_Compensation_Animated.gif)

### Opto 22 PID loop control

Opto 22 provides two basic ways to do PID loop control.

- In your control program—You can configure and graphically tune PID control loops while developing your control program in [PAC Control](#) software. Your program runs on a [SNAP PAC](#) standalone, rack-mounted, or PC-based programmable automation controller.
- On an I/O processor (*brain*)—If you are using a different PAC or a PLC, you can use the 96 built-in PID loops available in all [SNAP PAC I/O processors](#) (*brains*) to provide distributed intelligence. Your PID control loop continues to run locally even if communications with the controller are lost.

In both cases you're using reliable Opto 22 [SNAP I/O](#) for connections to field devices. Analog and digital SNAP I/O modules come in a wide variety of signal types, with 2 to 32 I/O points individually configurable for different signals. Each module is tested—twice—before it leaves our factory and headquarters in Temecula, California. Most I/O modules are **guaranteed for life**.

Product support on all Opto 22 products is free and provided by experienced engineers in our California headquarters.

For more information on Opto22 PID loops, see the following resources:

- [Basic information on PID loop control](#) and Opto 22's options for PIDs
- [OptoForum post](#) with a wealth of detailed information on using PIDs in PAC Control
- [Tutorial on PID loops](#) designed for use with a [SNAP PAC Learning Center](#), a self-contained system of hardware, software, sensors, and actuators for learning about automation and the SNAP PAC System.

For more information about Opto 22 and automation products, visit [opto22.com](http://opto22.com) or [contact our Pre-sales Engineers online](#) or by phone: 800-321-6786 (toll-free in the U.S. and Canada) or 1+951-695-3000