

This product is obsolete.

OPTO 22

DATA SHEET

Form 645-230124

INTERFACES CONTROLLER ISA

page 1/2


Description

G4LC32ISAARC

Part Number	Description
G4LC32ISAARC	ISA ARCNET Adapter for G4LC32ISA

**** This product is OBSOLETE and no longer available. ****

The following diagram shows the physical layout of the G4LC32ISAARC daughter board.



G4LC32ISAARC Jumpers

- JP1 Jumper
This jumper is not installed and is reserved for future use.
- JP2 Jumper
This jumper is not installed and is reserved for future use.

Cables and Connectors

- The following is suggested cable wire and connectors to make your custom ARCNET cable.
- Cable Wire: RG62A/U Coaxial Cable
Manufacturer: Belden
- Connectors: BNC Connectors
- Terminators: 93 Ohms

This product is obsolete.

OPTO 22

DATA SHEET

Form 645-230124

INTERFACES CONTROLLER ISA

page 2/2

Installation **[OBSOLETE]**

This section describes how to install a G4LC32ISAARC card into your computer. Please refer to the owner's manual for your computer for information on opening and removing the computer's cover.

To install the daughter cards into the computer:

1. Find an unoccupied 8- or 16-bit ISA expansion slot adjacent to the G4LC32ISA card.
2. Remove the expansion slot cover if one is installed.
3. Discharge any static electricity you may have by touching the computer's metal chassis.
4. Attach one end of the cable included with the daughter board card to the daughter board, and the other to the G4LC32ISA.
5. Install the card by orienting the computer connector facing the expansion slot and the mounting bracket facing the access port.

Specifications **[OBSOLETE]**

Power Requirements	5 VDC \pm 0.25 V @ 0.5A
Operating Temperature	0°C to 70°C
Storage Temperature	-25°C to 85°C
Humidity	5% to 95% Relative Humidity
Transfer Rate	2.5Mb/s
Weight	0.1 Kg

PRODUCTS

Opto 22 develops and manufactures reliable, easy-to-use, open standards-based hardware and software products. Industrial automation, process control, remote monitoring, data acquisition, and industrial internet of things (IIoT) applications worldwide all rely on Opto 22.

groov RIO®

groov RIO edge I/O offers a single, compact, PoE-powered industrial package with web-based configuration and IIoT software built in, support for multiple OT and IT protocols, and security features like a device firewall, data encryption, and user account control.

Standing alone, groov RIO connects to sensors, equipment, and legacy systems, collecting and securely publishing data from field to cloud. Choose a universal I/O model with thousands of possible field I/O configurations, with or without Ignition from Inductive Automation®, or a RIO EMU energy monitoring unit that reports 64 energy data values from 3-phase loads up to 600 VAC, Delta or Wye.

You can also use groov RIO with a Modbus/TCP master or as remote I/O for a groov EPIC system.

groov EPIC® System

Opto 22's groov Edge Programmable Industrial Controller (EPIC) system gives you industrially hardened control with a flexible Linux®-based processor with gateway functions, guaranteed-for-life I/O, and software for your automation and IIoT applications.

groov EPIC Processor

The heart of the system is the groov EPIC processor. It handles a wide range of digital, analog, and serial functions for data collection, remote monitoring, process control, and discrete and hybrid manufacturing.

In addition, the EPIC provides secure data communications among physical assets, control systems, software applications, and online services, both on premises and in the cloud. No industrial PC needed.

Configuring and troubleshooting I/O and networking is easier with the EPIC's integrated high-resolution color touchscreen. Authorized users can manage the system locally on the touchscreen, on a monitor connected via the HDMI or USB ports, or on a PC or mobile device with a web browser.

groov EPIC I/O

groov I/O connects locally to sensors and equipment. Modules have a spring-clamp terminal strip, integrated wireway, swing-away cover, and LEDs indicating module health and discrete channel status. groov I/O is hot swappable, UL Hazardous Locations approved, and ATEX compliant.

groov EPIC Software

The groov EPIC processor comes ready to run the software you need:

- Programming: Choose flowchart-based PAC Control, CODESYS Development System for IEC61131-3 compliant programs, or secure shell access (SSH) to the Linux OS for custom applications
- Node-RED for creating simple IIoT logic flows from pre-built nodes
- Efficient MQTT data communications with string or Sparkplug data formats
- Multiple OPC UA server options
- HMI: groov View to build your own HMI viewable on touchscreen, PCs, and mobile devices; PAC Display for a

Windows HMI; Node-RED dashboard UI

- Ignition or Ignition Edge® from Inductive Automation (requires license purchase) with OPC-UA drivers to Allen-Bradley®, Siemens®, and other control systems, and MQTT communications

Older products

From solid state relays, to world-famous G4 and SNAP I/O, to SNAP PAC controllers, older Opto 22 products are still supported and working hard at thousands of installations worldwide. You can count on us for the reliability and service you expect, now and in the future.

QUALITY

Founded in 1974, Opto 22 has established a worldwide reputation for high-quality products. All are made in the U.S.A. at our manufacturing facility in Temecula, California.

Because we test each product twice before it leaves our factory rather than testing a sample of each batch, we can afford to guarantee most solid-state relays and optically isolated I/O modules for life.

FREE PRODUCT SUPPORT

Opto 22's California-based Product Support Group offers free technical support for Opto 22 products from engineers with decades of training and experience. Support is available in English and Spanish by phone or email, Monday–Friday, 7 a.m. to 5 p.m. PST.

Support is always available on our website, including [free online training](#) at OptoU, how-to [videos](#), [user's guides](#), the Opto 22 KnowledgeBase, and [OptoForums](#).

PURCHASING OPTO 22 PRODUCTS

Opto 22 products are sold directly and through a worldwide network of distributors, partners, and system integrators. For more information, contact Opto 22 headquarters at **800-321-6786** (toll-free in the U.S. and Canada) or **+1-951-695-3000**, or visit our website at www.opto22.com.

